

# Hitachi Storage Advisor 3.3

---

## User Guide

Learn how to create, edit, and manage parity groups, pools, and volumes, protect data, monitor block storage, and create and manage file storage resources with Storage Advisor. You can also manage virtual storage machines and migrate volumes.

© 2019 Hitachi, Ltd. All rights reserved.

No part of this publication may be reproduced or transmitted in any form or by any means, electronic or mechanical, including copying and recording, or stored in a database or retrieval system for commercial purposes without the express written permission of Hitachi, Ltd., or Hitachi Vantara Corporation (collectively "Hitachi"). Licensee may make copies of the Materials provided that any such copy is: (i) created as an essential step in utilization of the Software as licensed and is used in no other manner; or (ii) used for archival purposes. Licensee may not make any other copies of the Materials. "Materials" mean text, data, photographs, graphics, audio, video and documents.

Hitachi reserves the right to make changes to this Material at any time without notice and assumes no responsibility for its use. The Materials contain the most current information available at the time of publication.

Some of the features described in the Materials might not be currently available. Refer to the most recent product announcement for information about feature and product availability, or contact Hitachi Vantara Corporation at [https://support.hitachivantara.com/en\\_us/contact-us.html](https://support.hitachivantara.com/en_us/contact-us.html).

**Notice:** Hitachi products and services can be ordered only under the terms and conditions of the applicable Hitachi agreements. The use of Hitachi products is governed by the terms of your agreements with Hitachi Vantara Corporation.

By using this software, you agree that you are responsible for:

1. Acquiring the relevant consents as may be required under local privacy laws or otherwise from authorized employees and other individuals; and
2. Verifying that your data continues to be held, retrieved, deleted, or otherwise processed in accordance with relevant laws.

**Notice on Export Controls.** The technical data and technology inherent in this Document may be subject to U.S. export control laws, including the U.S. Export Administration Act and its associated regulations, and may be subject to export or import regulations in other countries. Reader agrees to comply strictly with all such regulations and acknowledges that Reader has the responsibility to obtain licenses to export, re-export, or import the Document and any Compliant Products.

Hitachi is a registered trademark of Hitachi, Ltd., in the United States and other countries.

AIX, AS/400e, DB2, Domino, DS6000, DS8000, Enterprise Storage Server, eServer, FICON, FlashCopy, IBM, Lotus, MVS, OS/390, PowerPC, RS/6000, S/390, System z9, System z10, Tivoli, z/OS, z9, z10, z13, z/VM, and z/VSE are registered trademarks or trademarks of International Business Machines Corporation.

Active Directory, ActiveX, Bing, Excel, Hyper-V, Internet Explorer, the Internet Explorer logo, Microsoft, the Microsoft Corporate Logo, MS-DOS, Outlook, PowerPoint, SharePoint, Silverlight, SmartScreen, SQL Server, Visual Basic, Visual C++, Visual Studio, Windows, the Windows logo, Windows Azure, Windows PowerShell, Windows Server, the Windows start button, and Windows Vista are registered trademarks or trademarks of Microsoft Corporation. Microsoft product screen shots are reprinted with permission from Microsoft Corporation.

All other trademarks, service marks, and company names in this document or website are properties of their respective owners.

---

# Contents

<b>Preface.....</b>	<b>7</b>
Intended Audience.....	7
Product version.....	7
Release notes.....	8
Document conventions.....	8
Conventions for storage capacity values.....	9
Accessing product documentation.....	10
Getting help.....	10
Comments.....	11
<b>Chapter 1: Getting started.....</b>	<b>12</b>
Overview of Storage Advisor.....	12
Unified management of block storage and file storage.....	13
Dashboard.....	14
Analyzing data in the dashboard.....	18
Inventory and resource information.....	20
Onboarding a storage system workflow.....	21
Configuring a storage system workflow.....	22
Creating and attaching volumes to servers workflow.....	22
<b>Chapter 2: Adding a storage system.....</b>	<b>23</b>
<b>Chapter 3: Configure block storage.....</b>	<b>25</b>
Managing port security and settings.....	25
Editing iSCSI port settings.....	26
Adding a fabric switch.....	27
Supported fabric switch models.....	28
Creating parity groups .....	29
Creating parity groups, basic method.....	30
Creating parity groups or hot spares, advanced method.....	32
Managing free and spare disks.....	34
Parity groups inventory.....	34
External parity groups inventory.....	37
Enabling accelerated compression in Storage Advisor.....	38
Creating a pool.....	38

Pools inventory.....	39
Creating a pool, basic method.....	40
How Storage Advisor calculates pool sizes for the basic method of pool creation.....	43
Creating a pool, advanced method.....	43
Pool details.....	45
Create, attach, and protect volumes with local replication.....	49
Creating volumes to attach to servers.....	49
Attaching newly-created volumes to servers.....	51
Managing storage systems.....	53
Storage system inventory.....	53
Storage system details.....	54
Using NAS Manager for advanced file storage configuration.....	61
Using Storage Advisor with Storage Advisor Embedded.....	62
Updating a storage system.....	63
Managing servers.....	63
Adding servers.....	63
Server inventory.....	66
Server details.....	67
Updating a server.....	69
Edit LUN paths.....	70
Managing volumes.....	72
About capacity saving.....	72
Creating volumes.....	72
Attaching existing volumes to a server.....	74
Update a volume.....	77
Volumes inventory.....	77
<b>Chapter 4: Configure file storage.....</b>	<b>80</b>
Managing file pools.....	80
File pool inventory.....	80
Creating file pools.....	81
File pool details.....	83
Expanding a file pool.....	83
Managing virtual file servers.....	84
Virtual file server inventory.....	84
Creating a virtual file server.....	84
Virtual file server details.....	85
Managing file systems.....	85
File system inventory.....	85
Creating file systems.....	86
File system details.....	86

Updating a file system.....	87
Managing shares and exports.....	87
Shares and exports inventory.....	87
Creating shares and exports.....	88
Export details.....	88
Updating an export.....	88
Share details.....	89
Adding existing account domain groups to a share.....	89
Updating a share.....	90
<b>Chapter 5: Data protection.....</b>	<b>92</b>
Data protection concepts.....	92
Selecting volumes to protect.....	93
Protect volumes with local replication.....	93
Protecting volumes by cloning.....	93
Protecting volumes by creating snapshots.....	94
Protect existing volumes with high availability.....	95
Viewing replication groups.....	99
Replication groups inventory.....	99
Editing replication groups.....	101
Volume details.....	102
Global-active device.....	103
Virtual storage machines.....	103
<b>Chapter 6: Provisioning for high availability.....</b>	<b>105</b>
Prerequisites to provisioning for high availability.....	105
Register Data Instance Director in Storage Advisor.....	106
Create, attach, and protect volumes with high availability.....	107
Attach volumes and select secondary servers.....	109
Select volume protection options.....	110
Configuring connections to the primary and secondary sites.....	111
<b>Chapter 7: Manage virtual storage machines.....</b>	<b>113</b>
Creating virtual storage machines.....	113
Virtual storage machine inventory.....	114
Remove undefined resources from a virtual storage machine.....	115
Move volumes to a virtual storage machine.....	115
Add undefined resources to a virtual storage machine.....	116
Virtual storage machine details.....	118
Physical storage system details.....	118
<b>Chapter 8: Migrate volumes.....</b>	<b>121</b>
Volume migration workflow.....	121

External migration of volumes over 4TiB.....	122
Attaching volumes to storage when the source is managed in Storage Advisor (for external migration).....	123
Discovering external storage.....	123
Discovering and virtualizing volumes.....	124
Migrating volumes.....	125
Managing external volumes.....	126
Managing migration tasks.....	127
Editing a volume migration task.....	128
Interrupting an in-progress volume migration.....	128
Workflow for clean-up after migration.....	129
Deleting a volume migration task.....	129
Unvirtualizing external volumes.....	130
Detaching volumes from storage.....	130
Shredding volumes.....	130
<b>Chapter 9: Monitor block storage.....</b>	<b>132</b>
Monitoring capacity.....	132
Monitoring hardware.....	133
Monitoring data protection.....	134
Monitoring jobs.....	135
Setting up to receive SNMP alerts.....	136
<b>Chapter 10: Administer Storage Advisor.....</b>	<b>139</b>
Administering security.....	139
Privileges and roles.....	139
Adding an account domain.....	140
Assigning user roles.....	141
Backup and restore system settings.....	142
System elements preserved during backup.....	143
Download the system log file.....	143
<b>Index.....</b>	<b>144</b>

---

## Preface

Hitachi Storage Advisor is an infrastructure management solution that unifies storage management solutions such as storage provisioning, data protection, and storage management; simplifies the management of large scale data centers by providing smarter software services; and is extensible to provide better programmability and better control.

## Intended Audience

This document is intended for system administrators, Hitachi Vantara representatives, and authorized service providers who configure and operate the following storage systems with Hitachi Storage Advisor:

- Hitachi Virtual Storage Platform F350, F370, F700, F900
- Virtual Storage Platform F400, F600, F800
- Virtual Storage Platform F1500
- Virtual Storage Platform G350, G370, G700, G900
- Virtual Storage Platform G200, G400, G600, G800
- Virtual Storage Platform G1000
- Virtual Storage Platform G1500

Readers of this document should be familiar with the following:

- RAID storage systems and their basic functions.
- Volume creation and management.
- Pool creation and management.
- Parity group creation and management.

## Product version

This document revision applies to Hitachi Storage Advisor version 3.3 or later.

## Release notes

Read the release notes before installing and using this product. They may contain requirements or restrictions that are not fully described in this document or updates or corrections to this document.

Release notes are located on Support Connect at <https://knowledge.hitachivantara.com/Documents>.

## Document conventions





This document uses the following typographic conventions:

Convention	Description
<b>Bold</b>	<ul style="list-style-type: none"> <li>Indicates text in a window, including window titles, menus, menu options, buttons, fields, and labels. Example: Click <b>OK</b>.</li> <li>Indicates emphasized words in list items.</li> </ul>
<i>Italic</i>	<ul style="list-style-type: none"> <li>Indicates a document title or emphasized words in text.</li> <li>Indicates a variable, which is a placeholder for actual text provided by the user or for output by the system. Example: <code>pairedisplay -g group</code></li> </ul> <p>(For exceptions to this convention for variables, see the entry for angle brackets.)</p>
Monospace	Indicates text that is displayed on screen or entered by the user. Example: <code>pairedisplay -g oradb</code>
< > angle brackets	<p>Indicates variables in the following scenarios:</p> <ul style="list-style-type: none"> <li>Variables are not clearly separated from the surrounding text or from other variables. Example: <code>Status-&lt;report-name&gt;&lt;file-version&gt;.csv</code></li> <li>Variables in headings.</li> </ul>
[ ] square brackets	Indicates optional values. Example: [ a   b ] indicates that you can choose a, b, or nothing.
{ } braces	Indicates required or expected values. Example: { a   b } indicates that you must choose either a or b.



Convention	Description
vertical bar	Indicates that you have a choice between two or more options or arguments. Examples: [ a   b ] indicates that you can choose a, b, or nothing. { a   b } indicates that you must choose either a or b.

This document uses the following icons to draw attention to information:

Icon	Label	Description
	Note	Calls attention to important or additional information.
	Tip	Provides helpful information, guidelines, or suggestions for performing tasks more effectively.
	Caution	Warns the user of adverse conditions and/or consequences (for example, disruptive operations, data loss, or a system crash).
	WARNING	Warns the user of a hazardous situation which, if not avoided, could result in death or serious injury.

## Conventions for storage capacity values

Physical storage capacity values (for example, disk drive capacity) are calculated based on the following values:

Physical capacity unit	Value
1 kilobyte (KB)	1,000 (10 <sup>3</sup> ) bytes
1 megabyte (MB)	1,000 KB or 1,000 <sup>2</sup> bytes
1 gigabyte (GB)	1,000 MB or 1,000 <sup>3</sup> bytes
1 terabyte (TB)	1,000 GB or 1,000 <sup>4</sup> bytes
1 petabyte (PB)	1,000 TB or 1,000 <sup>5</sup> bytes
1 exabyte (EB)	1,000 PB or 1,000 <sup>6</sup> bytes

Logical capacity values (for example, logical device capacity, cache memory capacity) are calculated based on the following values:

Logical capacity unit	Value
1 block	512 bytes
1 cylinder	Mainframe: 870 KiB Open-systems <ul style="list-style-type: none"> <li>OPEN-V: 960 KiB</li> <li>Others: 720 KiB</li> </ul>
1 KiB	1,024 ( $2^{10}$ ) bytes
1 MiB	1,024 KiB or $1,024^2$ bytes
1 GiB	1,024 MiB or $1,024^3$ bytes
1 TiB	1,024 GiB or $1,024^4$ bytes
1 PiB	1,024 TiB or $1,024^5$ bytes
1 EiB	1,024 PiB or $1,024^6$ bytes

## Accessing product documentation

Product user documentation is available on Hitachi Vantara Support Connect: <https://knowledge.hitachivantara.com/Documents>. Check this site for the most current documentation, including important updates that may have been made after the release of the product.

## Getting help

[Hitachi Vantara Support Connect](https://support.hitachivantara.com/en_us/contact-us.html) is the destination for technical support of products and solutions sold by Hitachi Vantara. To contact technical support, log on to Hitachi Vantara Support Connect for contact information: [https://support.hitachivantara.com/en\\_us/contact-us.html](https://support.hitachivantara.com/en_us/contact-us.html).

[Hitachi Vantara Community](https://community.hitachivantara.com) is a global online community for Hitachi Vantara customers, partners, independent software vendors, employees, and prospects. It is the destination to get answers, discover insights, and make connections. **Join the conversation today!** Go to [community.hitachivantara.com](https://community.hitachivantara.com), register, and complete your profile.

## Comments

Please send us your comments on this document to [doc.comments@hitachivantara.com](mailto:doc.comments@hitachivantara.com). Include the document title and number, including the revision level (for example, -07), and refer to specific sections and paragraphs whenever possible. All comments become the property of Hitachi Vantara Corporation.

**Thank you!**

---

## Chapter 1: Getting started

Hitachi Storage Advisor is a unified software management tool that reduces the complexity of managing storage systems by simplifying the setup, management, and maintenance of storage resources.

- ▶ [" Get Started with Hitachi Storage Advisor - VSP Family"](#)
- ▶ ["Get Started with Hitachi Storage Advisor - VSP Gx00 with NAS modules"](#)
- ▶ ["Configuring the Hitachi Storage Advisor Environment with the Virtual Appliance Manager Tool"](#)
- ▶ ["Easy Provisioning with Hitachi Storage Advisor"](#)
- ▶ ["Easy Pool Creation with Hitachi Storage Advisor"](#)
- ▶ ["Migrating External Volumes with Hitachi Storage Advisor"](#)

These videos provide guidance to configure block and file storage by providing step-by-step workflow instructions with guided steps and UI transitions explaining each step.

You can also read the following white paper that explains how Storage Advisor handles industry requirements:

[Management Abstraction With Hitachi Storage Advisor](#)

You can review the following to gain an understanding of Storage Advisor concepts:

## Overview of Storage Advisor

Hitachi Storage Advisor is a unified software management tool that reduces the complexity of managing storage systems by simplifying the setup, management, and maintenance of storage resources.

Storage Advisor reduces infrastructure management complexities and enables a new simplified approach to managing storage infrastructures. It provides intuitive graphical user interfaces and recommended configuration practices to streamline system configurations and storage management operations. You can leverage Storage Advisor to easily provision new storage capacity for business applications without requiring in-depth knowledge of the underlying infrastructure resource details. It provides centralized management while reducing the number of steps to configure, optimize, and deploy new infrastructure resources.



Some of the key Storage Advisor capabilities include:

- Simplified user experience for managing infrastructure resources. Visual aids enable easy viewing and interpretation of key management information, such as used and available capacity, and guide features to help quickly determine appropriate next steps for a given management task.
- Recommended system configurations to speed initial storage system setup and accelerate new infrastructure resource deployments.
- Integrated configuration workflows with Hitachi recommended practices to streamline storage provisioning and data protection tasks.
- Common, centralized management for supported storage systems.
- A REST-based API to provide full management programmability and control in addition to unified file-based management support.
- Storage Advisor enables automated SAN zoning during volume attach and detach. Optional auto-zoning eliminates the need for repetitive zoning tasks to be performed on the switch.

## Unified management of block storage and file storage

Storage Advisor can be used to onboard and configure both block storage and file storage if NAS modules are included in the chassis of a supported storage system.

## Understand block and file storage

- Block storage:

In block storage, volumes of storage are created. A server-based operating system can connect to each block of storage and control it as an individual hard drive. Each storage block can be individually formatted with the required file system, such as NTFS or VMFS. Block storage systems are typically deployed in a Storage Area Network (SAN) environment.

From the dashboard of Storage Advisor, you can discover, register, and onboard a block storage system.

- File storage:

Storage Advisor supports unified onboarding and configuration of file storage in the form of NAS modules.

If a supported storage system includes NAS modules, the file storage is automatically added with the block storage. Then file pools and other file resources can be created in the Storage Advisor interface or by using the API.

## Adding block and file storage together

Storage Advisor enables you to add block and file storage in a single step. The only requirements are the service processor (SVP) IP address, user name, and password. When the file storage is added, the cluster is automatically registered in Storage Advisor.

## Unified configuration

Once a storage system is onboarded, all block and file resources can be configured and managed from a single Storage System page. File pool creation workflow incorporates best practices that simplify workflow and enhance usability. The file pools are used to easily create virtual file servers, file systems, and shares and exports. File system creation automatically mounts and formats the new file system.

## Unified reporting


Capacity is reported for all aggregated storage systems in the dashboard.

Capacity is also displayed for each storage system in the Storage System detail page.

Three views of capacity are available: file only, block only, or a unified view of block and file.

## Dashboard

Once a storage system has been onboarded to Storage Advisor, the dashboard displays as soon as you log in. The Storage Advisor dashboard provides the tools to easily configure, manage, and monitor storage systems.



From the Storage Advisor dashboard, you can access managed resources and provision storage in the context of a given storage system or server. The provided templates and configurations make it possible to quickly and easily provision a storage system, without knowing the details of the underlying hardware and software.

The top navigation menu provides access to Jobs and Monitoring pages. Links to the following settings are available, based on the user role:

- Tier Management
- Security Settings
- SNMP Settings
- Change Local Password
- Data Instance Director Settings

The dashboard has three distinct sections:

- **Resource side panel:** The left pane provides quick access to review the configuration of your storage systems, servers, and fabric switches. If the storage system includes NAS modules, virtual file servers can also be accessed. .
- **Alert tiles:** Four alert tiles represent various aspects of the health of the storage system. When Storage Advisor detects a problem with a storage system environment, a number appears in the tile. The number indicates the number of alerts for that aspect of the storage system. Click the alert tile to go directly to a summary of the problems.
- **Resource summary:** The middle area, with the information gauge, provides a summary of the capacity allocated from the registered storage systems.

### Resource side panel

The resource side panel enables quick access to storage systems and to servers.

- Click **Storage Systems** to view and add storage systems.
- Click **Servers** to view and add servers.
- Click **Fabric Switches** to view and add fabric switches.

- Click **Virtual File Servers** to view and add virtual file servers. Displays if the storage system includes NAS modules.
- Click **Virtual Storage Machines** to view virtual storage machines and move volumes to a VSM or add and remove undefined resources.

### Alert tiles

Across the top of the dashboard are tiles that display alerts for storage capacity, data protection, jobs, and hardware.

If a tile includes a circled check mark, there are no alerts for that part of the storage system, and everything is functioning normally. A number in a red circle within a tile indicates one or more problems with that part of the storage system.

You can click a tile for Capacity Alerts, Data Protection Alerts, or Hardware Alerts to view the summary for the category in the Monitoring tab.

The Jobs Alert tile displays the number of jobs in the last 24 hours with a status of **Failed** or **Success with Errors**.

### Resource summary

The circular information gauge displays capacity metrics for the available storage.

- If the storage systems include file storage, you can click **Block** or **File** next to the information gauge to view a legend and capacity values for either type of storage. Click **Unified** to view a legend and capacity values for both block and file.
- For block-only storage systems, the numerical data for each capacity parameter in the ring is displayed to the left of the information gauge.
- The number in the center of the rings shows the total usable capacity of all storage systems. The total usable capacity is the capacity available from all the parity groups across all storage systems.

If you do not have any parity groups configured on the storage system, this number is zero and all other data points in the capacity visualization are zero.



**Note:** To understand uninitialized raw capacities, review the available unused disks on the detail page for each storage system.

- The light grey ring indicates the sum of all pool capacity available across all storage systems. The dark grey indicates the parity group capacity that is not yet allocated to pools.

If you do not have any pools created, the light grey ring indicates zero. As you create pools, this number increases to eventually become equal to the total usable capacity when you have consumed all parity groups for pool creation.



**Note:** Allocated to Pools plus Unallocated to Pools equals the Total Usable Capacity in the center of information gauge.



- The light green ring (Thin Used) indicates the storage utilization. As you create volumes on the pools and start consuming capacity, the utilization of thin pools increases and you will notice the value in green starting to increase.

If Thin Used starts to increase and get closer to your total pool capacity, that indicates that the pools may be starting to fill up.

- Physical capacity allocated to file pools is indicated by medium blue in the File view and by light blue in the Unified view.
- File pool utilization is indicated by light blue in the File view and by medium blue in the Unified view.
- File over-commit capacity is represented by darkest gray in the outer ring of the File view.
- The subscribed capacity of all volumes, as a percentage, is represented by white in the outermost ring in the Block and Unified views. If the white ring extends outside the circle, it indicates oversubscription. Capacity subscription beyond the total available capacity should not be an issue if your capacity utilization is well within the total capacity.
- Physical capacity, or total usable capacity across all parity groups, is represented by dark blue in the outermost ring in the Block view and Unified views.

If you notice the total pool capacity (light grey) and Thin used (light green) values getting closer to total capacity, you may be running out of storage on one or more storage systems and may need to add disks to increase storage capacity. Review the information gauge for each storage system to identify which storage system needs additional capacity. In addition, check disks for each storage system to determine if there is unused capacity available for parity group creation.

The right side of the resource summary offers alternate views:

- **Protection:** is the breakdown of data protection metrics including a representation of types of protected, unprotected, and secondary capacity and gauge of the total percentage of capacity protected.
- **Tier Breakdown:** is a visualization of the amount of each tier that is allocated to pools.
- **Savings:**
  - **Data Reduction:** The ratio of logical used capacity to the physical used capacity, for all compression and deduplication technologies.



**Note:** The value displayed as the capacity of data after reduction includes the size of meta-data and garbage data generated by the storage system in addition to user data. The value might temporarily be greater than the capacity of data before reduction.

- **Capacity Efficiency:** : The ratio of Thin Free plus Thin Used to the physical used capacity. Capacity efficiency is only calculated for volumes on HDP and HDT pools.
  - If disk-based compression is in use, either alone or in combination with controller-based compression, the physical used capacity is that resulting from disk-based compression alone.
  - If only controller-based compression is in use, the physical used capacity is that resulting from controller-based compression.
  - If no compression is in use then physical used capacity is the used capacity of the pool(s).

## Analyzing data in the dashboard

The dashboard is a visual display of the important information needed to analyze the overall capacity utilization and health of your storage system. It provides visual indicators such as total usable capacity, current utilization, data protection summary, and monitoring alerts.


### Analyzing data shown in alert tiles

The alert tiles collectively present the health of the storage system environment. In one glance you can verify that the overall health is sound if you see no alerts on the alert tiles. This means that there are no capacity or hardware issues in the environment, no failed jobs in the last 24 hours and that the data protection is working without any issues.

If there are any alerts, you can drill down to the relevant alert page to investigate the cause. Storage Advisor provides alerts for capacity utilization, hardware, data protection, and jobs status.

### Analyzing data in the information gauge

The information gauge provides a visual indication of the total capacity of all storage systems managed by Storage Advisor.



The capacity indicated in the center of the ring is the total usable capacity available via the configured parity groups. After you add a storage system and configure parity groups, the total capacity indicator will show the capacity from the newly added storage system. The Thin Used capacity (light green ring) indicates the total capacity that is currently being used. If the usage is around 70-80% of the total capacity, you may receive capacity alerts based on the thresholds set by your storage administrator. The default thresholds are 70% and 80%, and can be changed during pool creation.

The light grey ring that provides a sum of capacities of all pools in the systems should be closer to 100% capacity. This would mean that you are using your entire parity group capacity by allocating it to pools. If the Thin Used capacity ring (light green) nears the total capacity (light grey ring) then you may run out of pool capacity soon. In such a case, expand the pool to consume more capacity.

If you notice that the total pool capacity (light grey ring) and Thin used (light green ring) values are getting closer to total capacity, you may be running out of disk capacity on one or more storage systems and would need to add disk space to increase storage capacity. Before adding disk space:

- Review the information gauge for each storage system to identify which storage system needs additional capacity.
- Review unused disks for each storage system to determine if any raw unused capacity is available for parity group creation.

Capacity subscription beyond the total available capacity should not be an issue if your thin capacity utilization is well within the total capacity.

### Analyzing tier metrics

As parity groups are created, the various disk types become categorized into tiers. The tiers and corresponding disk types are shown below.

**Table 1 Tier definitions**

Tier	Disk type
Platinum	FMD, FMD DC2, SSD, and FMD HDE
Gold	SAS 15 k
Silver	SAS 10 k

Tier	Disk type
Bronze	SAS 7.2 k




**Note:** Adding all tier capacities together equals the Total Usable Capacity in the center of the information gauge.

### Analyzing data protection metrics

The balance of your protected primary volumes and secondary volumes depends on the number of copies you have chosen to maintain, and also on the type of the data protection technology being used. If you choose to set aside more volumes for data protection, then the overall usable capacity may be affected. On the other hand, if you have a large amount of unprotected data, you may want to consider data protection options.



**Note:** These data protection capacity numbers are based on oversubscribed allocations and as a result will correlate with the overall oversubscription percentage, not the usable capacity numbers represented in the rest of the information gauge.




## Inventory and resource information

The inventory pages display details about the storage system resources in Storage Advisor. These resources include storage systems, servers, ports, and pools, volumes, parity groups, external parity groups (if the storage system has external storage), and replication groups. If the storage system has NAS modules, resources will also include file pools, virtual file servers, file systems, and shares and exports. Common actions can be performed on the inventory pages, such as the following:

- You can select one or more resources and delete them.  
When you delete a storage system, you disassociate it from Storage Advisor. When you delete a pool or volume, the resource is de-provisioned and removed from the storage system.
- When a parity group is deleted, it is removed from the storage system and the disks used to create the parity group are no longer in use. You can delete the parity group if you want to reconfigure the storage system with some other RAID configuration or simply decommission the array. If the parity group is in use by a pool, the parity group deletion will fail.
- You can select one or more of the same type of resources and update their properties. The properties that can be updated depend on the type of resource.
- You can click a particular resource to see more details about it on its resource detail page.
  - When you delete a block pool, the parity groups used by the pool will no longer be in In Use status. The pool volumes on these parity groups will be formatted and the parity group will eventually be in Available status.
  - When you delete a volume, the pool subscription will go down. Volume deletion will fail if the volume participates in data protection or is attached to a server.
  - When you delete a file pool, the underlying related block pool is deleted.
  - When you delete a server, the server is disassociated from Storage Advisor. You will no longer be able to provision volumes to the server (or its WWNs). Server deletion will fail if it has volumes attached to it.

## Onboarding a storage system workflow

When you onboard a storage system, you associate it with Storage Advisor so that you can manage it from the dashboard. Then you can add servers to which you can attach volumes. Optionally, you can add fabric switches if you want to auto-create zones during volume provisioning.



**Note:** If you use resource groups, make sure that the SVP username used to onboard storage systems in Storage Advisor has access to all custom resource groups and meta resource groups.

## Configuring a storage system workflow

Configure a storage system in order to manage storage using Storage Advisor.



**Note:** Storage Advisor retrieves and displays any resources that already exist in the storage system.

Complete the following in order to configure a storage system:

- Enable port security. Port security must be enabled for a host storage domain (HSD) to be created on the port. If port security is disabled Storage Advisor will not select the port for HSD creation. If the user manually selects the port with security disabled, the host group will be created.
- Create parity groups so you can create pools.
- Create pools so you can create volumes.



## Creating and attaching volumes to servers workflow

Storage Advisor provides a workflow in a single page to create volumes and immediately attach them to servers. Optionally, you can protect volumes as part of the same workflow.

You begin by choosing a server where you want to create and attach volumes. As part of the workflow, Storage Advisor automatically attaches volumes to servers after you select settings. Finally, you are provided the option of immediately applying data protection.



---

## Chapter 2: Adding a storage system

Onboarding a storage system is the process of associating it with Storage Advisor. After the storage system is onboarded, manage it from the Storage Advisor dashboard.

You can add multiple storage systems at once by specifying an SVP IP address that has multiple storage systems. Storage systems with different credentials cannot be added in the same operation.

To add a storage system without an SVP, you can specify either of the GUM IP addresses.

If a supported storage system includes NAS modules, the file storage will be added automatically along with the block storage.

Storage Advisor also supports onboarding of 4-node clusters, which is a requirement for GAD Enhanced for NAS. GAD Enhanced for NAS takes advantage of global-active device to cluster two VSP Gx00 models systems with NAS modules across two sites.

### Before you begin

Storage Advisor requires access to all resources groups on the storage system so that the workflows function correctly. Verify that the service processor (SVP) user name used to onboard a storage system in Storage Advisor has access to all custom resource groups and meta resource groups.

The user must be a member of the Administration Users Group.

If the storage system includes NAS modules, the user must also be a member of the Support Personnel Group.

### Procedure

1. On the Storage Advisor dashboard, click **Storage Systems** on the left pane.
2. Click the plus sign (+) to add a storage system.
3. Enter values for the following parameters on the **Onboard Storage System** page.
  - **IP Address:** For a storage system with an SVP, enter the IP address of the external service processor for the storage system you want to discover.
  - **User name and password:** Log in as a user that has administrator privileges on this storage system. For example, you can log in as the user `maintenance`.
4. Click **Submit**.



**Note:** For storage systems with both block and file storage, do not change the default Supervisor credentials.

## Result

When you successfully add a 4-node cluster, a message displays requesting that you ensure both storage systems in the global-active device pair are added before performing operations.

The Jobs tab is updated with the job called `Create Storage System`. If multiple storage systems are being added, there will be a job for each one.

Wait a while for the storage system to be added. Refresh the Jobs tab to verify that storage system is onboarded.

The dashboard shows the displayed number of storage systems has been incremented by one. Additionally, when you click Storage Systems, you are redirected to the storage system inventory where you can see the newly added storage system.

When a storage system is onboarded, Storage Advisor goes through an initialization process where it gathers the information about the current configuration of the storage system. During this time you will see that the ports, volumes, pools, and parity groups in the storage system are "Not accessible". Once the initialization is complete, you can see the port, pool, volume, and parity group information in the storage system details.



**Note:** If operations are performed outside of Storage Advisor, it takes time to update in Storage Advisor (approximately 20 minutes, depending on cache refresh).

## Next steps

1. In the parity group inventory for the storage system, create parity groups to convert the raw disk capacity into usable capacity.
2. From the settings menu, access the tier definitions before creating pools.



## Chapter 3: Configure block storage


Use Storage Advisor to configure the block storage.

### Managing port security and settings

Before a host storage domain (HSD) can be created on a port, port security must be enabled. By default, security is disabled on supported storage systems. If port security is disabled Storage Advisor will not select the port for host storage domain (HSD) creation. If you select a port that has security disabled, you are limited to the default host group. If the user manually selects the port with security disabled, the host group will be created.

#### Procedure

1. On the Storage Advisor dashboard, click **Storage Systems** to see the inventory of storage systems and capacity information.
2. Click a storage system to see its configuration of pools, ports, volumes, and parity groups.
3. Click **Ports** to see the configured storage ports for the storage system.



4. To modify ports do one of the following:
  - Select one or more Fibre Channel ports and click **Edit Fibre Port** to open the **Edit Fibre Port** page, where you can change the security setting.
  - Select an iSCSI port and click **Edit iSCSI Port** to open the **Edit iSCSI Port** page, where you can change security settings and IPv4 or IPv6 settings.
5. For a VSP G1000, VSP G1500, or VSP F1500 storage system, you can update port attributes by selecting one of the following:
  - **Target:** Fibre target port
  - **Initiator:** MCU initiator port
  - **RCU Target:** RCU target port
  - **External:** External initiator port
6. Click **Enable Security** or **Disable Security** and then click **OK**.  
A job is started to update the port security.

### Modifying port attributes in Storage Navigator

You can open the Ports inventory page in Storage Navigator by clicking Open the Ports/ Hosts Groups/iSCSI Targets page in Storage Navigator to view and modify port attributes.

For more information, refer to the Storage Navigator online help.



**Note:** Any changes you make in Storage Navigator may not be reflected in Storage Advisor for a few minutes.

## Editing iSCSI port settings

Change the settings for port security and for IPv4 and IPv6.

### Procedure

1. Navigate to the **Ports** page and select the **iSCSI** tab.
2. Select the port and click **Edit iSCSI** settings.

3. Update the port security or the settings for IPv4 and IPv6 and click **Submit**.

## Adding a fabric switch

You can add a fabric switch after onboarding a storage system. Add, update, and delete fabric switches in the Storage Advisor interface.

After a fabric switch is added, you can choose to auto-create zones during volume provisioning. A fabric switch is required for any operations that use auto-select, such as host group creation and auto-selection of ports while attaching volumes to servers.

### Before you begin

- Verify that servers and ports are connected according to the manufacturer's instructions.
- Verify that there is an active zone set with at least one dummy zone available.
- The Storage Advisor server is connected to the same IP network and has access to SNMP broadcast of Fibre Channel switches.
- Verify the required information about the fabric switch: Virtual Fabric ID (required only for Cisco switches), Fabric Switch Type, Fabric Switch IP Address, Port Number, Username, and Password.
- Verify that you have the Admin role for the fabric switch.

### Procedure

1. On the Storage Advisor dashboard, select **Fabric Switches** to open the **Fabric Switches** page.
2. Click the plus sign (+) to open the **Add Fabric Switches** page.

**Add Fabric Switches**

Add Fabric Switch Details

VIRTUAL FABRIC ID	FABRIC SWITCH TYPE	FABRIC SWITCH IP ADDRESS	PORT NUMB...	USERNAME	PASSWORD	
Virtual Fabric Id	Fabric Switch Type	Fabric Switch IP Address	22	AB	*****	+
Virtual Fabric Id	Fabric Switch Type	Fabric Switch IP Address	22	LM	*****	X

Cancel Submit

3. Enter the following information from the configuration of the switch you are adding:
  - **Virtual Fabric ID:** For Cisco switches, the VSAN ID. Not applicable to Brocade switches.
  - **Fabric Switch Type:** Select **Brocade** or **Cisco**.
  - **Fabric Switch IP Address**  
To add or update a core switch, use the Management IP address of the switch or the Active CP IP address.
  - **Port Number**
  - **Username**
  - **Password**
4. Click **Submit**.

### Result

A job is created to add the fabric switch.

## Supported fabric switch models

Storage Advisor supports a variety of Brocade® and Cisco® fabric switches.

### System requirements for Brocade switches

Model	Fiber OS version	Type
300	7.0 7.1 7.2 7.3	71
5300	7.0 7.1 7.2 7.3	64
6505	7.0 7.1 7.2 7.3	118
6510	7.0 7.1 7.2 7.3	109

Model	Fiber OS version	Type
6520	7.0 7.1 7.2 7.3	133
7800	7.0 7.1 7.2 7.3	83
DCX 8510-4	7.0 7.1 7.2 7.3	121
DCX 8510-8 with firmware v6.4	7.0 7.1 7.2 7.3	120

### System requirements for Cisco switches

Storage Advisor supports the Cisco MDS 9000 Series of switches.

Cisco MDS NX-OS Release 6.2(9) or later is required.

## Creating parity groups

Parity groups are the basic units of storage capacity. Creating parity groups converts the raw disk capacity in your storage system into usable capacity.

### Storage Advisor parity group concepts

Storage Advisor provides a simple one-click method of parity group creation that is based on best practices applicable to the disks in the storage system.

An advanced method of parity group creation is also available. You can choose to use the advanced method if there is not a need to rely on best practices.



**Note:** Parity groups on VSP G1000, VSP G1500, or VSP F1500 storage systems cannot be created in Storage Advisor. They are created by an authorized service representative. They can be initialized in Storage Advisor. Encryption can be enabled in Storage Navigator.

Creating parity groups in Storage Advisor also creates LDEVs that can be consumed for pool creation.

Encryption can be enabled during parity group creation if prerequisites are met, including a storage system with an Encryption Disk Board.

Normal practice is to use all available disk capacity when creating parity groups to ensure that all of the storage system capacity is usable. There can be exceptions to this practice; for example:

- If the entire capacity of the storage system is not needed.
- If there is a need to create fewer parity groups in order to reserve more disks as spares.

### Viewing parity groups

Access the Parity Groups page by clicking Storage Systems on the dashboard and then clicking a storage system tile. Click the Parity Groups tile.

A summary of parity groups includes disk type, number of parity groups, capacity, and available spares, all sorted by disk type.

- You can click Manage Spare Disks to open the Disk Management page and set free disks as spare disks, or spares as free disks.



**Note:** Not available for VSP G1000, VSP G1500, or VSP F1500.

- Click any parity group tile to view its details.
- Click the plus sign (+) to open the Create Parity Groups page.

When you open the Create Parity Groups page, the basic method is selected by default. Encryption can be enabled using either method.

- Basic option: Creating a parity group using the basic option requires no input, but you can change the RAID type or the number of parity groups. Storage Advisor applies recommended best practices for creating these parity groups.
- Advanced option: The advanced option allows the user to fully configure the RAID layout of the parity group by selecting the specific disks to assign for parity group creation.

### Enabling parity group encryption in Storage Navigator

Click Open the Parity Groups page in Storage Navigator to enable parity group encryption.

For more information, refer to the Storage Navigator online help.



**Note:** Any changes you make in Storage Navigator may not be reflected in Storage Advisor for a few minutes.

## Creating parity groups, basic method

The following procedure describes the basic option for creating a parity group and enabling encryption.



**Note:** Parity group creation on VSP G1000, VSP G1500, and VSP F1500 storage systems is performed outside Storage Advisor by an authorized service representative. Encryption can be enabled (if prerequisites are met) in Storage Advisor.

## Before you begin

- Register the storage system.
- Identify the target storage system name.
- Identify the total capacity that you expect to use. Plan to use all of the available disks in the system when you create parity groups.

## Procedure

1. On the Storage Advisor dashboard, select **Storage Systems** in the resource side panel to see the inventory of registered storage systems.
2. Click a storage system to create and configure the parity groups for it.
3. Click **Parity Groups** to see the inventory of all parity groups in the storage system.
4. Click the plus sign (+). In the **Create Parity Groups** window, review the list of unused disk types in the storage system. This information is grouped by disk type, disk speed, and disk capacity, and includes the following details:
  - Number of available disks.
  - Available spares detected for each disk type, disk speed, and capacity.
  - Number of new or additional spares to reserve. This calculation is based on the total spares needed based on recommended best practices, and the number of existing spares in the system.
  - The recommended RAID configuration for the disk type.
  - The number of parity groups that can be created.
  - The total usable capacity that is available based on the number of parity groups and the RAID configuration.

**Create Parity Groups**

Storage System **410500**

DISK TYPE	TOTAL DISKS	AVAILABLE D...	AVAILABLE S...	ADDITIONAL...	RAID TYPE	PARITY GRO...	USABLE CAPACITY	ENCRYPTION
SAS 10k 536.81 GB	96	19	5	0	RAID6 (6D+2P)	2	6.29 TiB	ON
SSD 366.80 GB	24	7	1	0	RAID1+0 (2D+2D)	1	733.60 GB	OFF

ENCRYPTION: ☒ ON ☐ OFF

Basic Advanced Cancel Submit

5. Decide if the recommended RAID configuration for each disk type is acceptable. Choose one of the following options:
  - Accept the recommended RAID configuration, which uses the full capacity of the installed drives.
  - Change the recommended RAID configuration or create fewer parity groups. Storage Advisor shows the number of parity groups that can be created for the new RAID configuration and the corresponding usable capacity.
6. (Optional) Click Encryption **ON** if you want to use encryption. Prerequisites for enabling encryption:
  - The storage system must have an Encryption Disk Board.
  - Encryption License Key must be installed.
  - The Key Management Server must be configured on the SVP.



**Note:** Encryption cannot be disabled in Storage Advisor.

7. Click **Submit**.

### Result

A job is started to create the parity group for the storage system. This job includes the following tasks:

- Identifies the appropriate number and position for the spare disk.
- Assigns a spare disk.
- Creates the required number of parity groups for the requested RAID layout.
- Creates and quick formats the necessary volumes on the parity group so that it is ready for pool creation.
- The job may create sub-jobs when multiple parity groups are being created. Each sub-job will show the status of the parity groups being created.

### Next steps

- Check the status of the parity group creation job by clicking Jobs.



**Note:** Parity group creation may take a long time.

## Creating parity groups or hot spares, advanced method

The advanced option enables users to configure parity groups that are not based on the provided best practices.

The advanced option allows you to fully configure the RAID layout of the parity group by selecting the specific disks and hot spares to assign for parity group creation.



**Note:** Parity groups on VSP G1000, VSP G1500, and VSP F1500 storage systems cannot be created in Storage Advisor. They are created by an authorized service representative. They can be initialized in Storage Advisor. Encryption can be enabled in Storage Navigator.

### Procedure

1. On the dashboard, click **Storage Systems** and click a storage system tile.
2. Click **Parity Groups** to open the **Parity Groups** page and click the plus sign to open the **Create Parity Groups** page.
3. Click **Advanced**.

4. Select a **RAID Type** and a **RAID Layout**.

RAID Type	RAID Layout
RAID5	3D+1P, 4D+1P, 6D+1P, 7D+1P
RAID6	6D+2P, 12D+2P, 14D+2P
RAID1+0	2D+2D

5. (Optional) Click Encryption **ON** if you want to use encryption.  
Prerequisites for enabling encryption:
  - The storage system must have an Encryption Disk Board.
  - Encryption License Key must be installed.
  - The Key Management Server must be configured on the SVP.

**Note:** Encryption cannot be disabled in Storage Advisor.

6. Choose available disks. Select enough disks to match the RAID Layout.

**Note:** FMD HDE drives with encryption disabled can be added to parity groups but the capacity cannot be used in pools.

7. Click **Submit**.

### Result

A job is started to create the parity group for the storage system.

### Next steps

- Check the status of the job by clicking Jobs.



**Note:** Parity group creation may take time.

- Create a pool.

## Managing free and spare disks

You can set free disks to spare and spare to free.



**Note:** Disk management is not available for VSP G1000, VSP G1500, and VSP F1500 storage systems.

If you choose to use the basic method to create parity groups, Storage Advisor will automatically review the available spare disks and allocate more spare disks if needed.

If you choose to create parity groups using the advanced method, you should review the number of spare disks in the parity groups inventory summary. If you want to assign more or fewer spare disks, use disk management.


### Procedure

1. On the dashboard, click **Storage Systems**.
2. Click a storage system tile and click **Parity Groups**.
3. Click **Manage Spare Disk** to open the **Disk Management** page and view disks not being used in any parity group.
4. Click **Disks to Set to Free** or **Disks to Set to Spare** and select one or more disks. Selecting Disks to Set to Spare will reserve the disks as a spare disks and they cannot be used for parity group creation. Selecting Disks to Set to Free will unallocate the spare disks and return them to the pool of available disks.
5. Click **Submit**.

## Parity groups inventory

After parity groups are created, they are displayed for each storage system.

To view parity groups for a storage system, click **Storage Systems** on the dashboard and click a storage system tile to view the associated parity groups, pools, volumes, and ports. Click **Parity Groups** to open the Parity Groups page.



You can perform the following actions on this page:

- If there are hardware alerts related to the parity groups, you can click the **Hardware Alerts** tile to view details for different types of components on the Monitoring page for the storage system.
- To assign free and spare disks, click **Manage Spare Disks** to open the Disk Management page.



**Note:** Disk management is not available for VSP G1000, VSP G1500, or VSP F1500 storage systems.

- Select one or more parity groups and do one of the following:
  - To initialize parity groups, click **Initialize Parity Groups**.  
You can create and initialize pool volumes on a parity group if pool volumes have not been created. You can also format any pool volumes that are in blocked state. You can initialize parity groups in the following conditions:
    - When the parity group either does not have any pool volumes or at least one of the pool volumes is in Blocked state. In this case, you will notice that the parity group status is UNINITIALIZED.
    - When the pool volumes on the parity group do not account for the entire parity group capacity and there are unused partitions on the parity group. In this case you will notice that the parity group status is Available but the available capacity is much less than the total capacity. This is supported only when the parity group status is AVAILABLE\_PHYSICAL, IN\_USE, or UNINITIALIZED.
  - To delete the parity group, click **Delete**. When you delete a parity group, it is removed from the storage system and the disks used to create the parity group are no longer in use. You can delete the parity group if you want to reconfigure the storage system with some other RAID configuration or simply decommission the array.



**Note:** The following parity groups cannot be deleted:

- Parity groups on VSP G1000, VSP G1500, or VSP F1500 storage systems.
- Parity groups that contain NAS boot volumes.

- To enable accelerated compression on parity groups, click **Enable Compression on Parity Groups**.

Compression can be enabled for unencrypted parity groups that were created using FMD DC2 or FMD HDE disks. The parity groups must also be in IN\_USE status.



**Note:**

The IN\_USE status means that the parity group is in a pool. You can create a pool on an existing parity group that was created using FMD DC2 or FMD HDE drives. Then identify the parity group in the detail page for the pool and enable compression in the Parity Groups page. Parity groups that contain NAS boot volumes cannot be compressed.

After compression is enabled, the status of the parity group is IN\_USE.

- Click the plus sign (+) to create a new parity group.



**Note:** Parity groups on a VSP G1000, VSP G1500, or VSP F1500 storage systems are created outside Storage Advisor by an authorized service representative.

- Use the filters to view the status of parity groups. Click a filter to apply it and click it again to remove it.
  - **AVAILABLE:** Parity group is not being used for any storage pools. It is available for pool creation.
  - **AVAILABLE\_PHYSICAL:** Parity group is not being used for any storage pools. Compression is enabled on the parity group and physical capacity of the parity group is available for pool creation. Not applicable to parity groups that are not enabled for compression.
  - **FORMATTED:** At least one of the pool volumes in the parity group is being formatted. The full format takes longer than a quick format because the service processor fully scans the hard drive.
  - **QUICK\_FORMATTING** At least one of the pool volumes in the parity group is being formatted using the quick format method. To make the formatting process quick, the drive is not fully checked, the files are still there, and the volume could be rebuilt to gain access to the files again.
  - **IN\_USE:** Parity group is being used by a storage pool.
  - **UNINITIALIZED:** The parity group either has no volumes or at least one of the pool volumes is in Blocked status, or one or more partitions is uninitialized and has a size greater than 16,787,456 blocks.
  - **UNSUPPORTED\_ATTACHED:** At least one of the pool volumes has a path to a storage port.
  - **UNSUPPORTED\_INACCESSIBLE\_RESOURCE\_GROUP:** Parity group and at least one of its pool volumes are in different resource groups and user does not have access to one of the resource groups.

## External parity groups inventory

External parity groups are parity groups in a storage system that is connected to a storage system that has been onboarded in Storage Advisor.

You can display a list of external parity groups in a storage system that has been registered with Storage Navigator.

You can access the External Parity Groups page by clicking the External Parity Groups tile on the detail page for a storage system. If the storage system has no external parity groups, the tile does not display.

External parity groups are not available for deletion, initialization, or compression.

If external parity groups have been used to create a pool (outside Storage Advisor), you can use their capacity to create volumes in Storage Advisor.

## Enabling accelerated compression in Storage Advisor

Accelerated compression can be enabled for parity groups on FMD DC2 or FMD HDE drives that are part of VSP Gx00 models, VSP Fx00 models and VSP G1000, VSP G1500, or VSP F1500 storage systems. It enable users to realize more virtual capacity than the actual usable capacity.



**Note:** Accelerated compression is not compatible with encryption. If a parity group is encrypted when created, the data cannot be compressed.

Storage Advisor only uses the physical capacity of the FMD DC2 or FMD HDE parity groups for which write is assured.

Accelerated compression can be enabled in the in the Parity Groups inventory page. The parity groups must be in IN\_USE status.

If a pool includes parity groups that have accelerated compression enabled, you can view the following in the detail page for the pool:

- **Expansion Ratio:** The ratio of the total capacity of FMD DC2 or FMD HDE pool volumes with respect to the total capacity of FMD DC2 or FMD HDE pool volumes assured for writing.
- **Compression Ratio:** The ratio of data size compression.
- **Savings %:** Displays the percentage of the capacity reduced by data compression with respect to the used capacity before the data compression. This will not display a value until data is compressed.

If the savings percentage for a pool is not high enough, you can provision additional pool volumes to the pool from the parity groups using FMD DC2 or FMD HDE drives.

## Creating a pool

Use the basic option to take advantage of tiers that are based on best practices.

If you want more flexibility and do not need to take advantage of best practices, you can use the advanced option to select specific parity groups.

You cannot create pools on external parity groups. They must be created outside Storage Advisor.

The types of pools are as follows:

- HDP (Dynamic Provisioning), which is functionality that allocates virtual volumes to a host and uses the physical capacity that is necessary according to the data write request.
- Tiered, which is used with Dynamic Provisioning and places data in a hardware tier according to the I/O load. For example, a data area that has a high I/O load is placed in a high-speed hardware tier, and a data area that has a low I/O load is placed in a low-speed hardware tier.
- HTI (Thin Image), which stores snapshot data in pools. A pool consists of multiple pool-VOLs. The pool-VOLs contain the snapshot data. A pool can contain up to 1,024 pool-VOLs.

## Pools inventory

Access the Pools page to add, update, and delete pools.

From the dashboard, click Storage Systems and then click a storage system tile to view parity groups, pools, volumes, and ports.

Click Pools to view the inventory of pools.



**Note:** If there are external pools (on external storage), they display in Pools inventory, but they cannot be added, updated, or deleted.



View pool details in either a tile view or a list view. Capacity utilization is represented by a color bar:

- **Green:** Below 70%.
- **Orange:** From 70% to 80%.
- **Red:** Over 80%.

A key in a tile or row indicates that the pool is encrypted.

You can filter the volumes as follows:

- **Pool Type:** Filter by the pool type: Thin, Tiered, , or Snap .
- **Pool Tier:** Filter by the pool tier: Platinum, Gold, Silver, Bronze, or External.
- **Active Flash Enabled:** Filter by whether Active Flash is enabled.
- **DDM Enabled** If True, the pool can be used to migrate volumes greater than 4TiB.
- **Encryption:** Filter by whether encryption is used. Select YES, NO, PARTIAL, or UNKNOWN.
- **FMD Compression:** Filter by whether a pool is using a parity group that is enabled for accelerated compression. Select YES, NO, PARTIAL, or UNKNOWN.
- **Deduplication Enabled:** Select YES or NO.

The following actions are available on this page:

- Click Open the Pools page in Storage Navigator to open the Pools page of Storage Navigator in a separate browser window.
- Select a pool and click Edit to update it in the Update Storage Pool page.
- Select one or more pools and click Delete to delete the pools. Deleted pools are de-provisioned and removed from the storage system.
- Click the plus sign (+) to add a pool in the Create Pool page.

### Opening the Pools inventory page in Storage Navigator

Click Open the Pools page in Storage Navigator to:

- Shrink or restore a HDP /HDT pool
- View the Tier properties of the HDT Pool
- Update the Monitoring Mode of the HDT pool (if Tier management is set to Manual)
- Start or stop the monitoring of the HDT pool (if Tier management is set to Manual)
- Start or stop tier relocation on the HDT pool (if Tier management is set to Manual)

For more information, refer to the Storage Navigator online help.



**Note:** Any changes you make in Storage Navigator may not be reflected in Storage Advisor for a few minutes.

## Creating a pool, basic method

Use the basic method of pool creation to create pools based on best practices.

### Before you begin

Create and configure parity groups on the storage system.

You need a minimum of four parity groups of the Bronze, Silver, or Gold tiers, or one parity group of the Platinum tier to create a pool using the basic method. Otherwise, you can use the advanced method of pool creation.



License requirements:

- For a Dynamic Tiering pool:  
Dynamic Tiering
- For a Thin pool: Dynamic Provisioning
- For a Thin Image pool: Thin Image
- For active flash: active flash

## Procedure

1. On the Storage Advisor dashboard, click **Storage Systems** to see the inventory of registered storage systems.
2. Click a storage system to create a pool for it.
3. Click **Pools**.
4. Click the plus sign (+) to open the **Create Pool** page.  
By default, the **Basic** option is selected.

The screenshot displays the 'Create Pool' configuration page. On the left, a dark sidebar contains a 'Pool Label' input field with the text '410395', a 'Storage System' dropdown menu, and a large circular graphic showing '0 GiB'. Below this, a legend identifies storage tiers: Platinum (blue), Gold (orange), Silver (green), Bronze (red), and External (grey). The main area on the right is titled 'Select capacity from Tiers to allocate to Pool' and contains a table with four rows, each representing a tier (Platinum, Gold, Silver, Bronze) and showing '0 GiB Available'. At the bottom of the main area, there are two sliders for 'Utilization Threshold (Low) %' and 'Utilization Threshold (High) %', and a 'Subscription Limit' input field set to '100'. A checkbox is checked below the sliders, stating 'if this threshold is exceeded, snapshots will be disabled to ensure there is enough capacity for user data.' At the very bottom, the 'Basic' tab is selected, and 'Advanced' is also visible. 'Cancel' and 'Submit' buttons are located in the bottom right corner.

5. Enter a **Pool Label**.  
Pool labels can contain only alphanumeric characters, hyphens, and underscores. Initial hyphens are not allowed.

6. In the **Select capacity from Tiers to Allocate to Pool** pane, you can choose storage from 1, 2, or a maximum of 3 tiers (**Platinum**, **Gold**, **Silver**, or **Bronze**).
  - If you select only one tier, you can use the **Intend to use for Snap?** toggle to decide whether to use Snap pools.
    - Click **Yes** to create Snap pools.



**Note:** Use this option if you want to use data protection to create snapshots. You can also create a pool for snapshots later by returning to the Create Pool page.

- Click **No** to create Dynamic Provisioning (DP) pools. These pools can also be used to create snapshots.
- If you select two or three tiers, the system creates Tiered pools.

**Table 2 Tier definitions**

Tier	Disk type
Platinum	FMD, FMD DC2, SSD, FMD HDE
Gold	SAS 15 k
Silver	SAS 10 k
Bronze	SAS 7.2 k

7. Click a selected tier to view the available storage capacity and select a capacity size.
8. Click **Tier Management** to see the disk type, capacity, and speed of each pool category.
9. Review the high and low pool utilization thresholds. The thresholds will serve as the Warning and Critical thresholds for monitoring capacity. Adjust the thresholds if needed.

If you are creating a Thin(DP) pool you can also choose whether to permanently suspend snapshots when usage exceeds the Critical threshold to reserve capacity for user data. If the threshold is exceeded, the pairs become suspended (PSUE) and the S-VOLs can never accept read-write operations. You can still write to P-VOLs. If this option is selected, a message displays in the Utilization graph in the detail page for the pool.



**Note:** This option is available for the following storage systems:

- VSP F1500, VSP G1000, and VSP G1500 with microcode version 80-05-4x and later.
- VSP F400, F600, F800 and VSP G200, G400, G600, G800 with firmware version 83-04-4x and later.
- VSP F350, F370, F700, F900 and VSP G350, G370, G700, G900.

10. Select the **Subscription Limit %** checkbox to set the limit to Unlimited.



**Note:** Subscription Limit % is not applicable to Snap pools or to the following storage systems: VSP F350, F370, F700, F900 and VSP G350, G370, G700, G900.

11. Click **Submit**.

### Result

A job is started to allocate the storage capacity and create the pool.

### Next steps

- Check the status of the pool creation job by clicking Jobs.
- Create a volume.

## How Storage Advisor calculates pool sizes for the basic method of pool creation

Storage Advisor incorporates best practices to calculate the best pool sizes based on the media available in the storage system. When the basic pool creation option is used, pool size is determined as follows:

- Storage Advisor identifies all the parity groups of the same disk type, disk capacity, disk speed, RAID type and layout and determines the available capacity of their usable LDEVs. Only parity groups in the Available and Quick Formatting states are eligible for pool creating using the basic method.
- Storage Advisor then uses combinations of these parity groups where four or more parity groups of the Bronze, Silver, or Gold tiers can be added together, or there is a parity group of the Platinum tier, to compute various possible pool sizes that can be created for the combination of disk type, disk capacity, disk speed, RAID type and layout.



**Note:** If your parity groups do not meet these requirements, you can only use the advanced method of pool creation.

- Based on the Storage System model, Storage Advisor determines the maximum pool size.
- Storage Advisor then displays the pools in increasing order of pool size.

## Creating a pool, advanced method

You can use the advanced method of pool creation to select parity groups filtered by disk type, speed, layout, and RAID level. This method does not employ best practices.



**Note:** Mixing different disk types in a Thin pool is not recommended. If you choose to create such a pool, Storage Advisor identifies the tier in this pool as "mixed".

### Before you begin

Create and configure parity groups on the storage system.

License requirements:

- For a Dynamic Tiering pool: Dynamic Tiering
- For a Thinpool: Dynamic Provisioning
- For a Thin Image pool: Thin Image
- For active flash: active flash

## Procedure

1. On the Storage Advisor dashboard, click **Storage Systems** to see the inventory of registered storage systems.
2. Click a storage system to create a pool for it.
3. Click **Pools**.
4. Click the plus sign (+) to open the **Create Pool** page and click **Advanced**.

5. Enter a **Pool Label**.  
Pool labels can contain only alphanumeric characters, hyphens, and underscores. Initial hyphens are not allowed.
6. Select **Yes** under **Intend to enable DDM** if you want to use the pool to migrate volumes greater than 4 TiB.
7. Click the **Type** list and choose one of the following; **DP**, **Tiered**, or **Snap**. You can create snapshots on Thin pools as well as on Snap pools.
8. Choose whether to enable active flash. active flash. requires capacity from the Platinum tier.
9. Click **Tier Management** to see the definitions of disk type, capacity, and speed of each pool category.
10. Select one or more parity groups to use to create the pool. You can scroll through the parity groups to use search and filter functions.

enablement requires capacity from the Platinum tier.

- For a Snap pool, select one or more parity groups with identical disk types.
- For a DP pool, select one or more parity groups with identical disk types.
- For a Tiered pool, select one or more parity groups with two or three disk types.

Storage Advisor shows the total size of the pool using the selected parity groups.

**11.** Set the utilization thresholds, or use the default threshold settings.

The thresholds are used as the Warning and Critical thresholds for Capacity Monitoring.

If you are creating a (HDP) pool you can also choose whether to permanently suspend snapshots when usage exceeds the Critical threshold to reserve capacity for user data. If the threshold is exceeded, the pairs become suspended (PSUE) and the S-VOLs can never accept read-write operations. You can still write to P-VOLs. If this option is selected, a message displays in the Utilization graph in the detail page for the pool.



**Note:** This option is available for the following storage systems:

- VSP F1500, VSP G1000, and VSP G1500 with microcode version 80-05-4x and later.
- VSP F400, F600, F800 and VSP G200, G400, G600, G800 with firmware version 83-04-4x and later.
- VSP F350, F370, F700, F900 and VSP G350, G370, G700, G900.

**12.** The subscription limit can be set above 100%. Select the **Subscription Limit %** checkbox to set the limit to Unlimited.



**Note:** Subscription Limit % is not applicable to Snap pools or to the following storage systems: VSP F350, F370, F700, F900 and VSP G350, G370, G700, G900.

**13.** Click **Submit**.

### Result

A job is started to allocate the storage capacity and create the pool.

### Next steps


- Check the status of the pool-creation job by clicking Jobs.
- Create volumes.

## Pool details

To access pool details, click **Storage Systems**. Then click a storage system to view all resources. Click **Pools** and then click a pool tile.



**Note:** An External pool cannot be edited or deleted.



On the pool details page, you can do the following:

- View the attributes of the pool.
- If the pool contains capacity that has had compression technology applied, you can view the following:
  - **Total Efficiency:** The ratio of the total saving effect achieved by accelerated compression, capacity saving (compression and deduplication), snapshot, and Hitachi Dynamic Provisioning.

Displays for the following storage systems with firmware version 88-03-0x or later: VSP F350, F370, F700, F900 and Virtual Storage Platform G350, G370, G700, G900.

- **Compression and Deduplication metrics**

- **Total Saving Ratio:** The capacity reduction ratio before and after capacity saving.
- **Compression Ratio:** The capacity compression ratio before and after capacity saving.
- **Deduplication Ratio:** The capacity deduplication ratio before and after capacity saving.
- **Pattern Matching Ratio:** The capacity reduction ratio before and after capacity saving pattern matching.

- **FMD Compression**

- **Total Saving Ratio:** The capacity reduction ratio before and after capacity saving.
- **Compression Ratio:** The capacity compression ratio before and after accelerated compression.
- **Pattern Matching Ratio:** The capacity reduction ratio before and after accelerated compression pattern matching.
- **Calculation End Time:** The end date and time for the calculation. The date and time are displayed in UTC.
- **Calculation Start Time:** The start date and time for the calculation. The date and time are displayed in UTC.
- **Provisioning Efficiency:** The efficiency ratio achieved by Dynamic Provisioning.

- **Capacity Efficiency:** The ratio of Thin Free plus Thin Used to the physical used capacity. Capacity efficiency is only calculated for volumes on Thin and Tiered pools.

Displays for any storage system other than VSP F350, F370, F700, F900 or VSP G350, G370, G700, G900 with firmware version 88-03-0x or later.

- If disk-based compression is in use, either alone or in combination with controller-based compression, the physical used capacity is that resulting from disk-based compression alone.
- If only controller-based compression is in use, the physical used capacity is that resulting from controller-based compression.

- If no compression then physical used capacity is the used capacity of the pool(s).
- **Data Reduction:** The ratio of logical used capacity to the physical used capacity, for all compression and deduplication technologies.



**Note:** The value displayed as the capacity of data after reduction includes the size of meta-data and garbage data generated by the storage system in addition to user data. For this reason, the value might be greater temporarily than the capacity of data before reduction.

- View a graph of utilization and thresholds.
- If the pool is based on a parity group using accelerated compression ("FMD DC2 Compression"), you can also view compression details, including expansion ratio and compression ratio.
- View tier information for the pool.

You can view:

- Tier management status

This is set to Automatic when the pool is created in Storage Advisor. To change this mode to Manual you must edit the pool using the SVP.

- Monitoring mode

Displays the monitoring mode set for the Tiered Pool. This is set to Continuous when the pool is created in Storage Advisor. To change the mode to Periodic, you must edit the pool using the SVP.

- Tier usage information

Displays the HDT Pool tier usage for the pools supported on the storage system. Storage Advisor supports Bronze, Silver, Gold, and Platinum tiers.

For each tier, you can display statistics for used capacity, performance utilization, and buffer space.

- View volumes carved from the pool and perform operations on them. Operations available include deletion, updating, attaching and detaching to and from servers, protecting, unprotecting, and restoring. Click a volume in tile or list view to open the detail page for the volume.

The Provisioning Status can be any of the following:

- **Attached:** the volume is attached to a server.
- **Unattached:** the volume is not attached to a server.
- **Unmanaged:** the volume has only a LUN path associated. For example, a volume may be attached to a server that is not known to Storage Advisor.

The Data Protection can be any of the following:

- **Protected:** the volume is protected.
- **Unprotected:** the volume is not protected.
- **Secondary:** the volume is a snapshot or clone of another volume.



- If the volume uses compression or deduplication and compression, you can view the compression ratio and deduplication ratio.
- Delete the pool.
- Edit the pool configuration by clicking the pencil icon to open the Update Storage Pool page.

Once a pool is created, you can edit the pool label or expand the pool. Basic and advanced options, similar to those for pool creation, are available for pool expansion. The basic option includes choices for a new/expanded pool size based on the current set of parity groups in the pool. You can choose to expand an existing tier in the pool or add a new tier to the pool. If you add a tier to a thin pool, it will be expanded and converted into a tiered pool. Using the advanced option enables you to add more parity groups to the pool and increase capacity.



**Note:** To expand a DP pool, you must add a parity group of the same RAID layout, the same disk type, the same RAID level, and the same disk speed.

Click **Submit** to update the window and start a job that will update the pool.

## Create, attach, and protect volumes with local replication

You can create volumes and attach them to servers and then apply data protection in a single workflow by first selecting a server.

### Creating volumes to attach to servers

Start the create-and-attach workflow by selecting a server and creating volumes.

When you create volumes in Storage Advisor you can:

- Create multiple volumes of the same size or different sizes at the same time.
- Select the specific pool for volume creation or let Storage Advisor automatically select the best pool based on utilization.
- Specify a common label and starting label suffix for identical volumes that are the same size and have the same pool requirement.

#### Before you begin

- Create parity groups.
- Create pools.
- Add servers.

#### Procedure

1. On the Storage Advisor dashboard, click **Servers** to see the inventory of servers.

2. Do one of the following to open the **Create, Attach and Protect Volumes** page:
  - Select a server, click **Attach Volumes**, and select **Create, Attach, and Protect Volumes with Local Replication**.
  - Click a server tile to open the **Server <ID>** details page. Click the cylinder icon (🔧) in the upper right area and select **Create, Attach and Protect Volumes with Local Replication**.

3. Configure volumes for the specified storage system.  
 You can switch to another storage system by using the drop-down **Storage System** list. If you want to add the volume to a virtual storage machine, use the **Virtual Storage Machine** list.
  - a. Select the number of volumes.
  - b. Enter the volume label and select a suffix for it.
  - c. Select the size.
  - d. Select the volume unit: **GiB**, **TiB**, or **PiB**.
  - e. Select the pool type: **Thin** or **Tiered**.
  - f. For a Thin pool, select the tier: **Platinum**, **Gold**, **Silver**, or **Bronze**.  
 If the storage system has available capacity from external storage, you can also select the **External** tier.
  - g. (Optional) Select the pool from the list of available pools. The default selection is **Auto Selected**, which means that Storage Advisor selects the best pool for provisioning the volume based on utilization and tier requirements.



**Note:** DDM pools are not available and cannot be used to create volumes.

4. If desired, select a type of **Capacity Saving: Compression** or **Deduplication and Compression**.



**Note:** Capacity saving can be set for volumes based on tiered pools only for VSP F1500, VSP G1000, and VSP G1500 models with microcode version 80-05-4x or later.



**Note:** If you choose **Deduplication and Compression** and later want to update the volume to **Compression** you must first disable **Capacity Saving**.

- When you have made your choices, click the plus sign (+) to add volume row to the list of volumes that will be created. Add more rows as needed.
- Click **Next** to be directed to attach volumes to the selected servers.

## Attaching newly-created volumes to servers

Storage Advisor provides options as part of the attachment of the new volumes to a single server or multiple servers.

**Create, Attach and Protect Volumes**

Progress indicators: Create Volumes (checked), **Attach Settings** (active), Create Paths, Protect Volumes.

**STORAGE SYSTEM**  
410031

**HOST MODE**  
AutoSelect

**HOST MODE OPTION**  
AutoSelect

**LUN ALIGNMENT**  
Yes No

**AUTO CREATE ZONE**  
Yes No

**Attach Settings**

# OF VOL.	LABEL	LABEL SUFF.	SIZE	POOL TYPE	TIER	POOL
1			1 GB	HDP	Platinum	Auto Selected

Buttons: Cancel Previous Next

### Procedure


- The **Host Mode** is set by default to the server operating system. You can make a selection if needed.  
The server OS Type is provided when the server is added to Storage Advisor.
- The prepopulated **Host Mode Option** will depend on the **Host Mode** selection. The default Host Mode Option can be changed manually.  
Default values are set only for **VMWARE EX** and **WIN EX** host modes. The default for all other Host Modes is none.  
Storage Advisor identifies all host groups containing any of the server WWNs. If all of those host groups have the same host mode and host mode options, those settings are prepopulated with the same settings in the host groups.

### 3. Select the **LUN Alignment**.

By default, Storage Advisor uses the LUN number that is common to the servers. If attachment is to only one server, this setting has no effect.

### 4. The **Auto Create Zone** is set to **No** by default. You can set it to **Yes** to automatically create zones.

### 5. Click **Next** to view options for creating and editing LUN paths.



### 6. In the **Create Paths** panel, you can view servers and their WWNs, along with ports on the storage system. Storage Advisor will scan for existing host groups on the storage array and attempt to reuse them by default.

The following options are available for managing LUN paths:

- If you connect more than one server to the same port, the **Share a host group with all servers** box displays. Select the box to add the servers to a single host group.
- **Note:** If host groups already exists on that port and single host group cannot be created, the checkbox will not appear.

To prevent the volume from being added to an existing path, click the path to highlight it and click **Delete Selected**.

Existing paths are populated as follows: all existing host groups with one or more server WWN and the exact same host mode and host mode options selected on the Attach Settings panel are populated as paths.

- Click **Suggest** to populate automatically selected paths. By default, the least-used ports are selected. Suggest paths requires that both server and storage ports be logged into the fabric switches in the Storage Advisor inventory.
- To manually create a path, click a WWN and a port to connect them with a blue connector line. Click the connector again and then click **Delete Selected** to delete the connection.

- When you are satisfied with the paths, click **Next** to view options for protecting volumes.

## Managing storage systems

Access the storage system details page for an overview of registered storage systems. If you need to configure the storage system, you will need to access the service processor with Storage Navigator.

### Storage system inventory

From the dashboard, click Storage Systems to access the Storage Systems page for an overview of registered storage systems.



The Storage Systems page includes a summary section identical to the summary on the dashboard. This includes monitoring tiles, capacity summary and data protection summary.

You can search for a specific storage system by searching for its serial number in the search box. You can also use various filters to find a specific storage systems.

From the storage systems page you can view and manage individual storage systems.

View storage system details in either a tile view or a list view. Capacity utilization is represented by a color bar:

- Green: Below 70%.
- Orange: From 70% to 80%.
- Red: Over 80%.


The following actions are available:

- Click a storage system to view details in the Storage System <serial number> page, where you can also access and manage the associated parity groups, pools, volumes, and ports.
- To delete a storage system, select it and click Delete.
- To edit the user name and password for a storage system, select it and click Edit to open the Update Storage System <serial number> page.

## Storage system details

View details about a storage system and access resources.

On the dashboard, click Storage Systems and then click a Storage System <serial number> tile.



If the storage system has no SVP, you can click Settings to access the following:

- Click **Launch Storage Advisor Embedded** to open Storage Advisor Embedded in a new browser.
- Click **Switch CTL to connect** to switch the IP address that Storage Advisor is using to communicate with the storage system. Use this option if Storage Advisor is unable to communicate with the storage system.

Click Savings to view the following for the following storage systems with firmware version 88-03-0x or later: VSP F350, F370, F700, F900 and VSP G350, G370, G700, G900.

For all other storage systems, Savings includes Data Reduction and Capacity Efficiency.

- **Total Efficiency:** The ratio of the total saving effect achieved by accelerated compression, capacity saving (compression and deduplication), snapshot, and Dynamic Provisioning.
- **Data Reduction:** The ratio of logical used capacity to the physical used capacity, for all compression and deduplication technologies.



**Note:** The value displayed as the capacity of data after reduction includes the size of meta-data and garbage data generated by the storage system in addition to user data. The value might temporarily be greater than the capacity of data before reduction.

- If disk-based compression is in use, either alone or in combination with controller-based compression, the physical used capacity is that resulting from disk-based compression alone.
- If only controller-based compression is in use, the physical used capacity is that resulting from controller-based compression.
- If no compression is in use then physical used capacity is the used capacity of the pool(s).
- **Capacity Efficiency :** The ratio of Thin Free plus Thin Used to the physical used capacity. Capacity efficiency is only calculated for volumes on HDP and HDT pools.
- **Provisioning Efficiency:** The efficiency ratio achieved by Dynamic Provisioning.
- **Snapshot Efficiency:** The efficiency ratio achieved by snapshot.

Click Details to view the foregoing metrics, plus the following components of Total Efficiency:

- **Software Compression and Deduplication**
  - **Total Saving Ratio:** The capacity reduction ratio before and after capacity saving.
  - **Compression Ratio:** The capacity compression ratio before and after capacity saving.
  - **Deduplication Ratio:** The capacity deduplication ratio before and after capacity saving.
  - **Pattern Matching Ratio:** The capacity reduction ratio before and after capacity saving pattern matching.
- **FMD Compression**
  - **Total Saving Ratio:** The capacity reduction ratio before and after accelerated compression.
  - **Compression Ratio:** The capacity compression ratio before and after accelerated compression.
  - **Pattern Matching Ratio:** The capacity reduction ratio before and after accelerated compression pattern matching.
  - **Calculation Period (UTC):** The start date and time for the calculation and the end date and time for the calculation.

The following actions are available:

- Click Delete to delete the storage system. This action is available only to users with the SystemAdministrator role.
- Click Edit to update the storage system user name and password. This action is available only to users with the SystemAdministrator role.
- Click Settings in the upper-right corner to launch the following:
  - cwStorage Navigator to perform any advanced storage management operations that are not available in Storage Advisor.
  - Configure storage system encryption using Storage Navigator.
  - If you have onboarded any of the following storage systems you can access Storage Advisor Embedded: VSP F350, F370, F700, F900 or VSP G350, G370, G700, G900. Click Launch Storage Advisor Embedded to log in to Storage Advisor Embedded.
  - If the storage system includes optional NAS module, you can launch NAS Manager to perform operations that are not available in Storage Advisor.
- Review the information gauge regarding available capacity in storage system.
- Use the Alerts tiles to access alerts related to the storage system.
- Click Review Tiered Categories to open the Tier Management page to view and edit tier categories.



- View attributes about the storage system, including information that Storage Advisor discovered about the system, such as model, serial number, and SVP IP address.

Field	Description	
Model	Model name of the storage system.	
S/N	Storage system serial number.	
SVP Version	SVP firmware version.	
HORCM Version	01-33-03/06 A data replication component residing on the server.	
Cache Capacity	Total cache capacity configured on the storage system.	
Unused Disks	Disks that are not assigned as hot spares or used to create parity groups.	
Unused Disk Capacity	Total unused capacity of all disks.	
SVP IP Address	Address of the service processor on the storage system.	
Maintenance Utility IP Addresses 1 and 2	Configured automatically when the storage system is onboarded.	
Health Status (for a cluster, if any)	Robust	Operating normally, with no failures in the cluster interconnect, the management network, or quorum device communication.
	Degraded	Operating, but one or more nodes has failed or there has been a failure in connectivity.
	Online	The cluster node is a part of the cluster and is exchanging heartbeats (periodic signals) with the other cluster members.
	Offline	Offline - The cluster node is no longer exchanging heartbeats with the other cluster members. This might be caused by a reboot or a fault condition. Services cannot be migrated to a cluster node in this state.
Status (of nodes, if any)	Dead	No heartbeats from this cluster node for a significant period. Services cannot be migrated to a cluster node in this state.

Field	Description	
	Unknown	Unknown - The node has not been online since the cluster was started.

- If you notice that the number of unused disks and unused disk capacity is too high, it implies that you have additional raw capacity in the system that can be converted into usable capacity by creating parity groups. Click Create Parity Groups to configure unused disks into parity groups.
- View the total and unused disk capacity for the different pool tiers.
- Click Review Tiered Categories to open the Tier Management page, where you can view the tier definitions and edit their names.
- Click a tile in the lower portion of the page to display the details for parity groups, pools, volumes, or ports for the storage system.

## Using Storage Navigator for advanced storage configuration

Storage Navigator is the element manager for a supported storage system block module. It is a factory-installed application running on the SVP, which is directly connected to the storage system. You can access Storage Navigator from the Storage System details page for advanced configuration options while performing management operations such as remote replication, volume migration, and resource group management with Storage Advisor.

Storage systems with an SVP cannot be managed using Storage Navigator.



**Note:** If you use Storage Navigator to manage resource groups, make sure that the user who adds storage systems in Storage Advisor has access to all custom resource groups and meta resource groups.

Use the Storage Navigator online help to obtain procedure information for advanced storage configuration tasks.

## Accessing Storage Navigator

Launch Storage Navigator from the Settings menu available in the Storage System details page. In the login dialog, use the user account assigned to you by your security administrator.

The tasks that you can do on the system depend on the user role assigned to the user groups to which you belong. Security administrators with view and modify privileges are responsible for setting up user accounts in Storage Navigator.

Refer to the Roles table for roles that are available for use in Storage Navigator and the permissions that each role provides to the users.

## Roles and permissions

The following table shows all the roles that are available for use and the permissions that each role provides to the users. You cannot create a custom role.



**Note:** The Support Personnel group and the Support Personnel (Vendor Only) role contain permissions to perform maintenance. Assign this role only to the accounts used by support personnel from vendors responsible for maintenance.

Role	Permissions
Security Administrator (View Only)	<ul style="list-style-type: none"> <li>▪ Viewing information about user accounts and encryption settings</li> <li>▪ Viewing information about the encryption key in the key SVP</li> </ul>
Security Administrator (View & Modify)	<ul style="list-style-type: none"> <li>▪ Configuring user accounts</li> <li>▪ Creating encryption keys and configuring encryption settings</li> <li>▪ Viewing and switching where encryption keys are generated</li> <li>▪ Backing up and restoring encryption keys</li> <li>▪ Deleting encryption keys backed up in the key SVP</li> <li>▪ Viewing and changing the password policy for backing up encryption keys on the management client</li> <li>▪ Connection to the external server</li> <li>▪ Backing up and restoring connection configuration to the external server</li> <li>▪ Configuring the certificate used for the SSL communication</li> <li>▪ Configuring the fibre channel authentication (FC-SP)</li> <li>▪ Configuring resource groups</li> <li>▪ Editing virtual management settings</li> <li>▪ Setting reserved attributes for global-active device</li> </ul>
Audit Log Administrator (View Only)	<ul style="list-style-type: none"> <li>▪ Viewing audit log information and downloading audit logs</li> </ul>
Audit Log Administrator (View & Modify)	<ul style="list-style-type: none"> <li>▪ Configuring audit log settings and downloading audit logs</li> </ul>
Storage Administrator (View Only)	<ul style="list-style-type: none"> <li>▪ Viewing storage system information</li> </ul>
Storage Administrator (Initial Configuration)	<ul style="list-style-type: none"> <li>▪ Configuring settings for storage systems</li> <li>▪ Configuring settings for SNMP</li> </ul>

Role	Permissions
	<ul style="list-style-type: none"> <li>Configuring settings for e-mail notification</li> <li>Configuring settings for license keys</li> <li>Viewing, deleting, and downloading storage configuration reports</li> <li>Acquiring all the information about the storage system and updating Device Manager - Storage Navigator window by clicking Refresh All</li> </ul>
Storage Administrator (System Resource Management)	<ul style="list-style-type: none"> <li>Configuring settings for CLPR</li> <li>Configuring settings for MP unit</li> <li>Deleting tasks and releasing exclusive locks of resources</li> <li>Configuring LUN security</li> <li>Configuring Server Priority Manager</li> <li>Configuring tiering policies</li> </ul>
Storage Administrator (Provisioning)	<ul style="list-style-type: none"> <li>Configuring caches</li> <li>Configuring volumes, pools, and virtual volumes</li> <li>Formatting and shredding volumes</li> <li>Configuring external volumes</li> <li>Configuring Dynamic Provisioning</li> <li>Configuring host groups, paths, and WWN</li> <li>Configuring Volume Migration except splitting Volume Migration pairs when using CCI</li> <li>Configuring access attributes for volumes</li> <li>Configuring LUN security</li> <li>Creating and deleting quorum disk used with global-active device</li> <li>Creating and deleting global-active device pairs</li> </ul>
Storage Administrator (Performance Management)	<ul style="list-style-type: none"> <li>Configuring monitoring</li> <li>Starting and stopping monitoring</li> </ul>
Storage Administrator (Local Copy)	<ul style="list-style-type: none"> <li>Performing pair operations for local copy</li> <li>Configuring environmental settings for local copy</li> <li>Splitting Volume Migration pairs when using CCI</li> </ul>
Storage Administrator (Remote Copy)	<ul style="list-style-type: none"> <li>Remote copy operations in general</li> <li>Operating global-active device pairs (except for creation and deletion)</li> </ul>
Support Personnel (Vendor Only)	<p>Configuring the SVP</p> <ul style="list-style-type: none"> <li>Normally, this role is for service representatives.</li> </ul>

Role	Permissions
Support Personnel (User)	<ul style="list-style-type: none"> <li>▪ Viewing storage system status</li> <li>▪ Installing OS security patches</li> <li>▪ Updating operating systems</li> <li>▪ Performing basic maintenance</li> </ul>

## Using NAS Manager for advanced file storage configuration

NAS Manager is the element manager for NAS modules. It is a factory-installed application running on the NAS modules. You can access NAS Manager from the Storage System details page for advanced configuration options while performing management operations such as data protection, server settings and network configuration.

Use the NAS Manager online help to obtain procedure information for advanced file storage configuration tasks.

### *Accessing NAS Manager*

Launch NAS Manager from the Settings menu available in the Storage System details page. In the login dialog, use the user account assigned to you by your administrator. The tasks that you can do on the system depend on your user role.

Refer to the Administrator types and responsibilities list for roles that are available for use in NAS Manager and the permissions that each role provides to the users.

### *Administrator types and responsibilities*

This section describes the types of NAS storage system administrators and defines their expected roles in managing the system and the associated storage subsystems.

- **Global Administrators** can manage everything in the system: file systems, file services, or file system related features and functions, storage devices and their components. Also, the Global Administrator creates and manages SMU user profiles (Server Administrators, Storage Administrators, Server+Storage Administrators, and other Global Administrators). Global Administrators also control what servers and storage devices each administrator can access.
- **Storage Administrators** manage storage devices, as specified in the administrator profile created by the Global Administrator.

Storage Administrators can manage only storage devices and their components (racks, physical disks, SDs, and storage pools). Storage Administrators cannot manage file systems, file services, or file system related features and functions, and they cannot manage users.

- **Server Administrators** manage servers and clusters, as specified in the administrator profile created by the Global Administrator. Server Administrators cannot manage storage devices.

Server Administrators can manage file systems and file services such as CIFS Shares, NFS Exports, and they can manage file system related features and functions such as snapshots, quotas, and migration policies and schedules.

- **Server+Storage Administrators** manage servers, clusters, and storage devices, as specified in the administrator profile created by the Global Administrator.

Server+Storage administrators can manage everything Server Administrators and Storage Administrators can manage: file systems, file services, or file system related features and functions, and they can also manage storage devices and their components.

All administrators can connect to the NAS storage system through NAS Manager, the browser-based management utility provided by the system management unit (SMU). Additionally, Global Administrators on an external or virtual SMU can connect to the SMU command line interface (CLI). SMU CLI access is not available on an embedded SMU or a NAS module SMU.

**Read-only users:** The above roles (when defined for local users or Active Directory groups) can be modified by making them read-only. A read-only user has permission to view most pages of the NAS Manager; however, they are not generally allowed to perform any actions on the NAS Manager that would trigger a system or configuration change.



**Note:** Server Administrators, Storage Administrators, and Server+Storage Administrators cannot access all of the NAS Manager pages that a Global Administrator can access.

## Using Storage Advisor with Storage Advisor Embedded

Storage Advisor Embedded provides management for a single storage system with a simple interface and intuitive navigation. It is part of the following storage systems: VSP F350, F370, F700, F900 and VSP G350, G370, G700, G900.

### Accessing Storage Advisor Embedded

Access Storage Advisor Embedded from the detail page of the storage system. Click Settings and select Launch Storage Advisor Embedded.

### Using Storage Advisor Embedded

You can access Storage Advisor Embedded to view storage system performance in real time and review capacity usage and data reduction.



**Note:** To review historical performance, you can access the performance monitor in Storage Navigator.

Storage Advisor Embedded allows you to quickly and easily create one-time snapshots and Snap Clones.

You can also use Storage Advisor Embedded to create pools and volumes and update ports.



**Note:** Resources created outside Storage Advisor will take a few minutes to update in Storage Advisor.

## Tier management

The Tier Management page displays the tier definitions. You can edit the tier names (Platinum, Gold, Silver, Bronze, and External).

Access the Tier Management page in one of these ways:

- Click **Settings** and select **Tier Management**.
- In the detail page for a storage system, click **Tier Management**.

## Updating a storage system

Update the user name and password for a storage system. This action requires the SystemAdministrator role be assigned to the user.

### Procedure

1. Log into Storage Navigator and create a new user.
2. Access the **Update Storage System <serial number>** page one of these ways:
  - On the **Storage Systems** page, select a storage system and click **Edit**.
  - On the **Storage System <serial number>** page, click **Edit**.
3. Edit the **Username** or **Password** and click **Submit**.

## Managing servers

Storage Advisor supports provisioning storage to a group of server WWNs by allowing logical servers to be managed by Storage Advisor. Once servers are onboarded in Storage Advisor, storage volumes can be provisioned to the servers by creating Host Storage Domains and optionally creating zones to provide a path between the storage volume and server.

## Adding servers

Add servers so you can attach volumes.

You can add multiple server parameters from a file, or add one server at a time.

There are two methods of adding servers:

- Manually add information for one server at a time.
- Import a CSV (comma-separated values) file with information for one server in each row.

The CSV file must have the following headings, in the order specified:

- For Fibre: Name, Description, IPAddress, OSType, WWNs (comma separated list of WWNs). All fields are required except Description and IPAddress.
- For iSCSI: Name, Description, IPAddress, OSType, IscsiName (comma separated list of names), ChapUser, ChapSecret. All fields are required except Description and IPAddress, ChapUser and ChapSecret.


Valid OSType values are as follows:

- AIX
- HP\_UX
- LINUX
- NETWARE
- OVMS
- SOLARIS
- TRU64
- VMWARE
- VMWARE\_EX
- WIN
- WIN\_EX

### Procedure

1. On the Storage Advisor dashboard, click **Servers**. Then click the plus sign (+) to open the **Add Server** page.





Add Servers

CSV Import

Fibre Servers

SERVER NAME	DESCRIPTION	IP ADDRESS	OS TYPE	
Host Name	Description	IP Address	HP_UX	
WWN				
50:00:00:00:00:00:00, 50:00:00:00:00:00:01				

iSCSI Servers

SERVER NAME	DESCRIPTION	IP ADDRESS	OS TYPE	
Host Name	Description	IP Address	HP_UX	
CHAP USER	CHAP SECRET	iSCSI NAMES		
sysadmin	*****	iqn.1992-01.com.company:db, iqn.1992-01.com.c...		

Cancel

Reset

Submit

2. On the **Add Server** page, do one of the following:
  - Click the upper plus sign (+) to browse for the CSV file or drag the file to the plus sign. The values from the file will populate the page. Example:

```
Name,Description,IPAddress,OSType,WWN5
Esxi,ESXI HOST,10.30.90.200,VMWARE_EX,10:00:00:05:33:26:f7:21
Win,WINDOWS
HOST,10.30.91.80,WIN_EX,"10:00:00:05:33:26:f7:37,10:00:00:05:3
3:26:f7:36"
ESXi_Cisco_1,ESXi HOST connected to Cisco
Fabric,,VMWARE_EX,"10:00:00:05:33:26:e0:fc,10:00:00:05:33:26:e
0:fd"
ESXi_Cisco_2,ESXi HOST connected to Cisco
Fabric,,VMWARE EX,"100000053326df1a,100000053326df1b"
```

- To add both Fibre and iSCSI servers, use the following format:

```
Name,Description,IPAddress,OSType,WVNS,IscsiNames,CHAPUserName,  
CHAPUserSecret  
linux-iscsi,test dummy host,20.10.10.10,Linux,,,"iqn. linux-  
iscsi-1,iqn. linux-iscsi-2,eui.1234567890abCDef",,,,  
-windows-iscsi-un-chap,test dummy  
host,20.10.10.20,Win,,,"iqn.-windows-iscsi-un-  
chap",chapUserName,chapUserSecret,,  
-windows-iscsi-bi-chap,test dummy host,20.10.10.30,Win,,,"iqn.-  
windows-iscsi-bi-  
chap",chapUserName,chapUserSecret,chapUserName,chapUserSecret  
-vmware-iscsi-longest,test dummy  
host,20.10.10.40,VMWARE,,,"iqn.12345678901234567890123456789012  
34567890123456789012345678901234567890123456789012345678901234  
56789012345678901234567890123456789012345678901234567890123456  
78901234567890123456789012345678901234567890123456789012345678  
9,eui.3234567890abCDef",,,,,  
ed801h,Windows,10.197.73.57,WIN,"10:00:00:90:fa:b4:a8:71"  
ed800n,ESX Host,10.197.73.7,VMWARE,"10:00:00:90:fa:55:85:5d"  
-linux,test dummy  
host,10.10.10.10,Linux,10:10:10:10:10:10:10:10:10:  
-windows,test dummy  
host,10.10.10.20,Win,10:10:10:10:10:10:10:10:20  
-vmware,test dummy  
host,10.10.10.30,VMWARE,10:10:10:10:10:10:10:10:30
```

- Click the plus sign (+) in the table to add a row and enter the required information for Fibre Channel or iSCSI. You can add more servers by clicking the plus sign again.


3. Click **Submit** to add the servers.

## Next steps

Create volumes and attach them to the server.

## Server inventory

The Servers page displays all servers and includes a graphic summary based on operating systems.



To find the server you are looking for, you can either search by server ID or narrow down the list of servers using filters available.

You can click server tiles on this page to access details of individual servers and manage their volumes.

The following actions are available on this page:

- To add a server, click the plus sign (+) to open the Add Servers page.
- You can select one or more servers and perform the following actions:
  - Click Delete to delete the server.
  - Click Edit to update server parameters.
  - Click Create and Attach Volumes to use the provided workflow to create new volumes, attach them to the server, and optionally, protect the volumes.
  - Click Attach Existing Volumes to attach existing volumes to the server.

## Server details


The Server details page provides you all the details about the server as well as a list of volumes, if any, attached to the server.

This page also shows path details for every volume attached to the server, including the storage ports and server WWNs used to create HSDs as well as the host mode options set up on the HSD.

You can perform server actions such as removing the server, editing the server or provisioning volumes to server by attaching existing volumes or creating and attaching new volumes.

You can perform volume operations such protecting or detaching volumes.

On the dashboard, click Servers to open the Servers inventory page. Then click a server tile to open the Server <ID> detail page for the selected server.



You can perform the following actions at the server level:

- Click Delete to remove the server.
- Click Edit to update server parameters.
- Click the cylinder icon (🔧) and select one of the following:
  - Attach Existing Volumes to attach volumes to the server.
  - Create and Attach Volumes to create volumes and attach them to the server.

The following actions are available for volumes:

- If there is a Data Protection Failed alert, you can click it to see failed data protection jobs on the Data Protection Monitoring page.
- Click Edit to rename a volume on the Update Volume page. If the volume is unprotected, you can also update the size.
- Click Edit LUN Path to open the Edit Paths page where you can update LUN paths.
- Click Detach Volumes to detach volumes from the server.
 

Before confirming, you can choose whether to remove SAN zones.
- Click Protect Volumes to protect volumes using Storage Advisor data protection technologies.
- Click Unprotect Volumes to remove data protection applied to volumes.
- Click Restore Volumes to restore from a backup.
- Click Attach to Storage to attach volumes to target storage to prepare for volume migration where source and target storage systems are both managed in Storage Advisor.
- Click Migrate Volumes to migrate volumes.

## Updating a server

You can change the parameters for an existing server.

### Procedure

1. Access the **Update Server** page in one of these ways:
  - From the dashboard, click **Servers** to open the inventory of servers. Select a server and click **Edit**.
  - On the detail page for a server, click the pencil icon.

Update Server

SERVER NAME	DESCRIPTION	IP ADDRESS	OS TYPE
RTN	Description	172.17.23.111	HP UX

Modify Existing WWNs

50:00:00:00:00:00:00

Add New WWNs

50:00:00:00:00:00:00

Reference WWN to Copy Path Connection Information from (Default: None)

+

☐ Apply changes to attached volumes

Cancel Submit

2. Edit any of the following for a server with the Fibre Channel protocol:
  - **Server Name**
  - **Description**
  - **IP Address**
  - **OS Type**
  - **Modify Existing WWNs**
  - **Add New WWNs**
    - a. If needed, add new WWNs and click the plus sign to add them to the list.
    - b. You can select a reference WWN to add the new WWN into host groups to which the reference WWN belongs.



**Note:** If reference WWN is specified, **Apply changes to attached volumes** must also be checked.

Click **Apply changes to attached volumes** to make the following changes:

- If a WWN has been updated, all host groups with the old WWN are updated with the new one. All zones created in Storage Advisor have the old WWN removed and new address populated.
- If a WWN is deleted, it will be removed from any host group that has it. If the host group is left with no WWNs, the entire host group is deleted. All zones created in Storage Advisor have the deleted WWN removed.
- If you add a reference WWN, host groups are edited. If you do not add a reference WWN, no host groups are edited. You can use Storage Advisor to add paths using the new LUN.
- Changes to name, description, IP address, or OS type do not impact host groups.

3. Edit any of the following for a server with the iSCSI protocol:

- **Server Name**
- **Description**
- **IP Address**
- **OS Type**
- **Modify Existing iSCSI Names**
- **Add New iSCSI Names**
- **Enable or Disable CHAP Settings.**
  - a. You can select a reference iSCSI name to add the modified or new iSCSI name into host groups to which the reference iSCSI belongs.
  - b. Select **Update CHAP Credential** to add a new CHAP user.
  - c. Click **Apply changes to attached volumes** to make the following changes:
    - If an iSCSI initiator name has been updated, all iSCSI targets with the old iSCSI name are updated with the new one.
    - If a iSCSI initiator name is deleted, it will be removed from any iSCSI target that has it. If the iSCSI target is left with no iSCSI initiator names, the entire iSCSI target is deleted.
    - If a iSCSI initiator name is added, no iSCSI targets are edited. You can use Storage Advisor to add paths using the new LUN.
    - If a CHAP user information changes, Storage Advisor will update the information on the storage system.
    - Changes to name, description, IP address, or OS type do not impact iSCSI targets.

## Edit LUN paths

Update LUN paths for volumes that are attached to a server.

If LUN paths become outdated, you can update them through the detail page for the server.

## Procedure

1. On the dashboard, click **Servers** and click the server that needs to be updated to open the detail page for the server.
2. Select one or more volumes for which you want to edit LUN paths and click **Edit LUN Path** to open the **Edit Paths** page.

**Edit Paths**

Attach Settings    Create Paths

**STORAGE SYSTEM**  
410500

**HOST MODE**  
WIN

**HOST MODE OPTION**  
None

**AUTO CREATE ZONE**  
Yes No

LABEL	ID	SIZE	LUN
ww	270 (0001:0E)	1.00 GiB	LUN (optional)

Cancel Next

3. The **Host Mode** is set by default to the server operating system. You can make a selection if needed.  
The server OS Type is provided when the server is added to Storage Advisor.
4. The prepopulated **Host Mode Option** will depend on the **Host Mode** selection. The default Host Mode Option can be changed manually.  
Default values are set only for **VMWARE EX** and **WIN EX** host modes. The default for all other Host Modes is none.  
Storage Advisor identifies all host groups containing any of the server WWNs. If all of those host groups have the same host mode and host mode options, those settings are prepopulated with the same settings in the host groups.
5. **Auto Create Zone** is set to No by default. You can set it to Yes to automatically create zones.
6. Click **Next**.
7. In the **Edit Paths** page, you can view servers and their WWNs, along with ports on the storage system.

Storage Advisor will scan for existing host groups on the storage system and attempt to reuse them by default. The following options are available for managing LUN paths:

- Existing paths are populated as follows: all existing host groups with one or more server WWNs and the exact same host mode and host mode options selected on the **Attach Settings** panel are populated as paths.
- To prevent the volume from being added to an existing path, click the path to highlight it and click **Delete Selected**.
- To manually create a path, click a WWN and a port to connect them with a blue connector line. Click the connector again and then click **Delete Selected** to delete the connection.

8. When you are satisfied with the paths, click **Submit**.

## Managing volumes

A volume is a single accessible storage area, created in a pool within a parity group on a storage system. Create a volume and manage its properties with Storage Advisor

### About capacity saving

Capacity saving reduces the used capacity of volumes.

Storage Advisor enables you to use capacity saving when you create or update a volume.

A capacity saving volume is a dynamically provisioned volume (DP-Vol) that is capable of compression or both deduplication and compression.

Storage Advisor offers the following capacity saving options:

- Compression  
Compression allows you to reduce the used capacity of your volume.
- Deduplication and compression  
Deduplication identifies duplicate data blocks in order to remove redundancy.
- No  
No data compression or deduplication is done.

### Creating volumes

Create volumes for a registered storage system so you can attach them to a server.



When you create volumes in Storage Advisor you can:

- Create multiple volumes of the same size or different sizes at the same time.
- Select the specific pool for volume creation or let Storage Advisor automatically select the best pool based on utilization.
- Specify a common label and starting label suffix for identical volumes that are the same size and have the same pool requirement.
- Set up compression, or deduplication and compression for the volume.

### Before you begin

- Create parity groups.
- Create pools.
- Add servers (optional).

### Procedure

1. On the Storage Advisor dashboard, click **Storage Systems** to see the inventory of storage systems and capacity information.
2. Click a storage system to see its configuration of servers, pools, ports, volumes, and parity groups.
3. Click **Volumes** to see the inventory of configured volumes for the storage system.
4. Click the plus sign (+) to open the **Create Volumes** page.

**Create Volumes**

STORAGE SYSTEM  
410209  
SUBSCRIBED CAPACITY  
79% (292.06 TiB)  
VIRTUAL STORAGE MACHINE  
No Virtualize

VOLUME LABEL: [Text Field] LABEL SUFFIX: [Text Field] NUMBER OF VOLUMES: [Text Field] SIZE: [Text Field] GiB  
Volume: [Text Field] 0 1  
POOL TYPE: [Text Field] POOL TIER: [Text Field] POOL: [Text Field] CAPACITY SAVING: [Text Field]  
Tiered - - Auto Selected No

NUMBER OF ...	VOLUME LABEL	LABEL SUFFIX	SIZE	UNIT	POOL TYPE	POOL TIER	POOL	CAPACITY SA...

Cancel Submit

5. Configure volumes for the specified storage system.
  - a. If you want to add the volume to a virtual storage machine, select one in the **Virtual Storage Machine** menu.
  - b. Enter the volume label (required) and select a suffix for it.
  - c. Select the number of volumes.
  - d. Select the size.
  - e. Select the volume unit: **GiB**, **TiB**, or **PiB**.

- f. Select the pool type: **Tiered** or **Thin**.
- g. For a Thin pool, select the **Tier**.  
If the storage system has available capacity from external storage, you can also select the **External** tier.
- h. You can select **Compression**, **Deduplication and Compression**, or **No** from the **Capacity Saving** drop down list.



**Note:** Capacity saving can be set for volumes based on tiered pools only for VSP F1500, VSP G1000, and VSP G1500 models with microcode version 80-05-4x or later.



**Note:** If you choose **Deduplication and Compression** and later want to update the volume to **Compression** you must first disable **Capacity Saving**.

- i. (Optional) Select the pool from the list of available pools. The default selection is **Auto Selected**, which means that Storage Advisor selects the best pool for provisioning the volume based on utilization and tier requirements.



**Note:** DDM pools are not available and cannot be used to create volumes.

- 6. Click the plus sign to move the configured volume to the lower portion of the **Create Volumes** page.  
A blank row appears at the top of the page where you can create more volumes.
- 7. Click **Submit**.

### Result

A job is started to create the volumes and add them to the volume inventory for the storage system.

### Next steps

- Check the status of the volume-creation job by clicking **Jobs**.
- Attach volumes to a server.

## Attaching existing volumes to a server

If there are volumes that have not been attached to servers, you can use this procedure to attach them.

### Before you begin


- Enable security on ports.
- Add servers.
- Create volumes.

## Procedure

- To select volumes and servers, do one of the following:
  - On the **Volumes** inventory page for a storage system, select one or more volumes and click **Attach Volumes** to select servers on the **Attach Volumes** page.
  - On the **Servers** inventory page, select one or more servers and click **Attach Volumes** to select volumes on the **Attach Volumes** page.
  - On the detail page for a pool, select one or more volumes and click **Attach Volumes** to select servers on the **Attach Volumes** page.
- Click **Next** to view options for attaching existing volumes.

LABEL	ID	SIZE	LUN
AutoVolume_dskorDelete	2 (00:00:02)	1.00 GiB	LUN (optional)

- The **Host Mode** is set by default to the server operating system. You can make a selection if needed.  
The server OS Type is provided when the server is added to Storage Advisor.
- The prepopulated **Host Mode Option** will depend on the **Host Mode** selection. The default Host Mode Option can be changed manually.  
Storage Advisor identifies all host groups containing any of the server WWNs. If all of those host groups have the same host mode and host mode options, those settings are prepopulated with the same settings in the host groups.  
Default values are set only for **VMWARE EX** and **WIN EX** host modes. The default for all other Host Modes is none.
- Select the **LUN Alignment**.  
By default, Storage Advisor uses the LUN number that is common to the servers. If attachment is to only one server, this setting has no effect.
- The **Auto Create Zone** is set to **No** by default. You can set it to **Yes** to automatically create zones.
- Click **Next** to view options for creating and editing LUN paths.



8. In the **Create Paths** panel, you can view servers and their WWNs, along with ports on the storage system. The following options are available for managing LUN paths: Storage Advisor will scan for existing host groups on the storage array and attempt to reuse them by default. The following options are available for managing LUN paths:

- If you connect more than one server to the same port, the **Share a host group with all servers** box displays. Select the box to add the servers to a single host group.



**Note:** If host groups already exists on that port and single host group cannot be created, the checkbox will not appear.

- Existing paths are populated as follows: all existing host groups with one or more server WWN and the exact same host mode and host mode options selected on the Attach Settings panel are populated as paths.  
To prevent the volume from being added to an existing path, click the path to highlight it and click **Delete Selected**.
- Click **Suggest** to populate automatically selected paths. By default, the least-used ports are selected.
- To manually create a path, click a WWN and a port to connect them with a blue connector line. Click the connector again and then click **Delete Selected** to delete the connection. Suggest paths requires that both server and storage ports be logged into the fabric switches in the Storage Advisor inventory.

9. When you are satisfied with the paths, click **Submit**.

## Update a volume

You can expand an unprotected volume and rename any volume. You can also enable or disable deduplication and compression.

### Procedure

1. Navigate to details for a single volume in one of these ways:
  - From the dashboard, click **Storage Systems** and then click a storage system tile to view its resources. Click **Volumes** and then click the volume tile for the volume you want to update.
  - From the dashboard, click **Servers** and then click a server tile to view its volumes. Click a volume tile for the volume you want to expand.
2. On the **Volume <ID>** page click **Edit** to open the **Update Volume** page.



**Note:** To reset a volume to the default settings, click **Reset**.

3. You can rename the volume, and if it is unprotected, you can change the size by clicking the up and down arrows next to the volume size.
4. Under **Change Compression Type**, select **Compression** or **Deduplication and Compression** to change the type. To disable compression, select **No**.



**Note:** If **Deduplication and Compression** is enabled and you want to update to **Compression** you must first update to **No** and then update again.

5. Click **Submit**.


### Result

A job is started to update the volume.

## Volumes inventory

The **Volumes** page enables you to filter, sort, and edit volumes for a single storage system, and to select volumes for data protection.

Access the inventory of volumes for a storage system to gain insight into volume size, data protection and utilization. You can also create volumes, attach existing volumes and perform data protection operations.



View volume details in either a tile view or a list view. Capacity utilization is represented by a color bar:

- Green: Below 70%.
- Orange: From 70% to 80%.
- Red: Over 80%.



**Note:** Volumes labeled **HSA-reserved** are created automatically when file pools are created and no operations can be performed on them in Storage Advisor.

The following actions are available on this page:

- If there are Data Protection Alerts, click the tile to view the alerts in the **Monitoring** tab.
- Click the plus sign (+) to add volumes on the Create Volumes page.
- Click a volume to view details and attach, update or delete the volume.

- Select a volume and click **Edit** to update the volume by editing the name or updating the Capacity Saving setting. . If the volume is unprotected you can also expand the capacity.
- Select one or more volumes to perform one of the following actions:
  - To delete volumes, click **Delete**. When you delete a volume, it is de-provisioned and removed from the storage system.



**Note:** If deduplication or compression has been enabled on the volume and the volume has data, it cannot be deleted in Storage Advisor. Access Storage Navigator to delete the volume.

- To attach existing volumes to one or more servers on the Attach Volumes page, click **Attach Volumes**.
- To apply data protection on the Protect Volumes page, click **Protect Volumes**.
- To suspend data protection, click **Suspend**.
- To resume data protection following suspension, click **Resume**.
- To unprotect a volume, select it and click **Unprotect**.



**Note:** A volume in an "External" replication group cannot be unprotected.

- To restore a secondary volume to the primary volume, click **Restore** to open the Restore Volume page.
- To attach the volume to a storage system to prepare for volume migration, click **Attach to Storage**.
- To migrate volumes, click **Migrate Volumes**.
- To shred volumes that have been migrated, click **Shred Volumes**.

### Opening the Volumes inventory page in Storage Navigator

Click **Open the Logical Devices page in Storage Navigator** to open the Volumes inventory page and:

- Create a Command Device from a volume
- Restore a blocked volume
- Migrate a volume from one pool to another

For more information, refer to the Storage Navigator online help.



**Note:** Any changes you make in Storage Navigator may not be reflected in Storage Advisor for a few minutes.

## Chapter 4: Configure file storage

To configure file storage, begin by creating file pools and virtual file servers. You need both to create file systems.

Then create file systems and use them to create shares and exports that you can use to offer storage to users.

### Managing file pools

Storage Advisor employs the following best practices in file pool creation:

- For creation of the related block pool, use of RAID6 with a minimum of four parity groups for SAS or one parity group for SSD, FMD, or FMD DC2.




**Note:** This best practice is highly recommended. If capacity is chosen from non-conforming parity groups during file pool creation, a warning displays.

- Creation of a Thin pool that comprises each selected tier (either one or two).
- Minimum disk requirements for file pool creation:
  - 24 disks for SAS 10K, 15K
  - 48 disks for SAS 7.2K
  - 8 disks for FMD, FMD DC2, SSD

When a user creates a file pool in Storage Advisor, the system automatically performs the following operations:


1. Identifies parity groups.
2. Creates a block pool.
3. Creates volumes and attaches them to NAS modules.
4. Configures volumes as system drives.
5. Creates a file pool.



### File pool inventory



Access the File Pools page from the detail page for a storage system.



Use this page to view file pool information in a tile or list view, and to delete or expand existing pools, as well as to create new pools.

The colored bars display used capacity, physical capacity allocated for use on the underlying block storage, and the file over-commit capacity. The over-commit capacity reflects the amount by which the file pool is over-subscribed.

Each tile or list row shows whether the file pool is tiered, its File Pool Label, and capacity utilization.

The following actions are available:

- Create a new file pool by clicking the plus (+) sign to open the Create File Pool page.
- Delete one or more file pools by selecting them and clicking Delete.
- Add capacity by selecting a file pool and clicking Expand to open the Expand File Pool page.
- Open the File Pool detail page for the file pool by clicking a File Pool Label.
- Click a HDP Pool [ID] link in a tile to open the detail page for the underlying block storage pool.

## Creating file pools

Create file pools to create file systems.

### Before you begin

The minimum disk requirements are:

- 24 disks for SAS 10K, 15K
- 48 disks for SAS 7.2K
- 8 disks for FMD, FMD DC2, SSD, or FMD HDE

You must also have a minimum number of parity groups. See the following table for a summary of both disk and parity group requirements:

Tier	Minimum number of disks	Minimum number of parity groups
Platinum	8	1
Gold	24	4
Silver	24	4
Bronze	48	6

Both of these requirements need to be met in order to create a file pool using Storage Advisor.

Examples of valid combinations:

- 1 or more 6D+2P SSD parity groups (Platinum)
- 2 or more 3D+1P SSD parity groups (Platinum)
- 4 or more 6D+2P SAS 15k Parity Groups (Gold)
- 4 or more 6D+2P SAS 10k parity groups (Silver)
- 6 or more 6D+2P SAS 7.2k parity groups (Bronze)

Examples of unacceptable combinations:

- 1 3D+1P SSD parity group (Platinum; meets only the 1 parity group requirement, not the 8 disk requirement.)
- 2 14D+2P SAS 10k parity groups (Silver; meets only the 24 disk requirement, not the 4 parity group requirement.)



**Note:** Storage Advisor only supports file pool creation from DP volumes and not from basic volumes created outside Storage Advisor.

### Procedure

1. On the **File Pools** page, click the plus (+) sign to open the **Create File Pool** page.
2. Enter a label for the file pool.
3. In the **Select Capacity for New File Pool** pane, choose storage from one or two tiers. For a tiered pool, select Platinum and one other tier.



**Note:** Best practices suggest that file over-commit capacity should be an estimated 200%. Best practices also include using RAID 6, with a minimum of four parity groups for SAS drives or one parity group for SSD, FMD, FMD DC2, or FMD HDE drives. If another RAID layout is selected, a warning displays.

The information gauge displays the total capacity, with the physical block capacity and estimated over-commit capacity also detailed.

The **Estimated Max Potential**: in IOPS displays after each type of capacity is selected.

**Table 3 Tier Definitions**

Pool Tier	Description
Platinum	SSD, FMD, FMD DC2, FMD HDE
Gold	SAS 15 k
Silver	SAS 10 k
Bronze	SAS 7.2 k

4. (Optional) Adjust the Utilization Thresholds.
5. Click **Submit**.  
A job is added to create the file pool.

## File pool details

Access the File Pool details page by clicking a **File Pool Label** in the File Pools page.

Use this page to view details about a file pool and to manage file systems in the pool.

You can search for a specific file system by searching for its File System Label in the search box. You can also use the Free Space and File Systems Size filters to find specific file systems, or filter by virtual file server.

View file system information in either a tile view or a list view, including capacity utilization and whether or not the file system is mounted.

Capacity utilization is represented by a color bar in each tile.

The following actions are available:

- Delete the file pool by clicking Delete.
- Expand the file pool by clicking Expand to open the Expand File Pool page.
- View details of an underlying block pool by clicking an HDP pool link in the file pool tile.
- Add a file system by clicking the plus (+) sign to open the Create File System page.
- Delete one or more file systems by selecting them and clicking Delete.
- Edit a file system by selecting it and clicking Edit to open the Update File System page where you can change the label or expand the file system.
- Select a file system and mount or unmount it.

## Expanding a file pool

File pool capacity may need to be expanded when the used capacity approaches the capacity of the underlying block pool.

You can also relabel a file pool or change utilization thresholds.

To access the Expand File Pool page do one of the following:

- In the File Pools page, select a file pool and click Expand.
- In any file pool detail page, click Expand.

### Procedure

1. To expand the file pool, select capacity from one of the tiers.  
An untiered file pool cannot be expanded into a tiered file pool.
2. If you want to change the file pool label, enter it in the **File Pool Label** field.
3. If you want to change utilization thresholds, use the sliders.
4. Click **Submit**.  
The job is added to the **Jobs** page.

## Managing virtual file servers

### Virtual file server inventory

Access the Virtual File Servers page from the dashboard or from the detail page for a storage system.

Use this page to view information about virtual file servers in a tile or list view. Use the filters to show only offline or online virtual file servers, or filter by blade number.

The following actions are available:

- Open the Create Virtual File Server page by clicking the plus (+) sign.
- Open the Virtual File Server detail page, where you can delete, edit, and enable or disable the virtual file server by clicking the virtual file server label in any tile or list row.
- Open the storage system detail page by clicking the Storage System [ID] link in any tile or list row.
- Delete one or more virtual file servers by selecting them and clicking Delete.
- Change the label for a virtual file server by selecting it and clicking Edit to access the Update Virtual File Server page.
- You can also Delete, Enable, or Disable by selecting a virtual file server and clicking the applicable icon.

### Creating a virtual file server

Create virtual file servers so you can create file systems.

**Before you begin**

- Configure ports.
- Obtain the required IP address and subnet mask information for the virtual file server.

**Procedure**

1. On the **Virtual File Servers** page, click the plus sign (+) to open the **Create Virtual File Server** page.
2. Enter a label for the virtual file server.
3. Enter the IP address (ipv4 or ipv6) for the virtual file server.
4. Enter the subnet mask for the virtual file server.
5. Select the cluster node Gigabit Ethernet port to which the IP address for the virtual file server is assigned.
6. Click **Submit**.  
A job is added on the **Jobs** page to create the virtual file server.

**Virtual file server details**

Access the Virtual File Server detail page from the Virtual File Servers page.

Use this page to manage a virtual file server's file systems.

The following actions are available:

- Open the storage system detail page by clicking a Storage System [ID].
- Select a file system in either the list or tile view and do one of the following:
  - Delete the file system by clicking Delete.
  - Expand a file system or change the label on the Update File System page by clicking Edit.
  - Click Mount or Unmount to mount or unmount the file system.
  - Open the File System detail page by clicking a file system.
  - Open the detail page for the underlying file pool by clicking the File Pool link in a tile.

**Managing file systems****File system inventory**

Access the File Systems page from the detail page for a storage system. Use this page to view information about file systems in a list or tile view, and to manage file systems.

You can search for a specific file system by searching for its file system label in the search box. You can also use the Free Space and File Systems Size filters to find specific file systems, or filter by virtual file server.

View file system details in either a tile view or a list view, including capacity utilization and whether or not the file system is mounted.

Capacity utilization is represented by a color bar in each tile.

The following actions are available:

- View details of a file system by clicking the file system label in a tile or row to open the File System detail page.
- Add a file system by clicking the plus (+) sign to open the Create File System page.
- Delete one or more file systems by selecting them and clicking Delete.
- Edit a file system by selecting it and clicking Edit to open the Update File System page.
- Select a file system and Mount or Unmount it.
- View details of the underlying pool by clicking a File Pool label in a tile.
- View details of the related virtual file server by clicking the VFS label in a tile.

## Creating file systems

Create file systems so that you can create shares on Windows and exports on Linux.

### Before you begin

Create file pools and virtual file servers.

### Procedure

1. Click the plus sign (+) on the **File Systems** page to open the **Create File System** page.
2. Select a virtual file server.
  - a. Enter a label up to 255 alphanumeric characters.
  - b. Select a format:
    - **4K**: This choice is best for small block random applications (Virtual Server / Virtual Desktops / Databases).
    - **32K**: This choice is best for large block sequential applications (Video, Media, Images) or when the file system is hosted on NL-SAS drives.
3. Enter capacity up to 1PiB.
4. Select a pool and click **Submit**.  
A job is added to the **Jobs** page to create the file system.

## File system details

Access the File System detail page from the File Systems page.

Use this page to create and manage shares and exports. You can also view information about a file system and access the associated file pool and virtual file server.

The following actions are available:

- Delete the file system by clicking Delete.
- Update label and capacity by clicking Edit to open the Update File System page.
- Mount or Unmount the file system by clicking Mount or Unmount.
- Access the file pool where the file system was created by clicking the File Pool [ID] link in the tile.
- Access the virtual file server where the file system was created by clicking the virtual file server label in the tile.
- Create a share or export by clicking the plus sign (+) to open the Create Shares/Exports page.
- Delete a share or export by selecting it and clicking Delete.
- Update a share or export by selecting it and clicking Edit to open the Update Share or Update Export page.

## Updating a file system

Update a file system to re-label or expand it.

### Procedure

1. On the **File Systems** page, select a file system and click **Edit** to open the **Update File System** page.
2. You can change the file system label, the capacity, or both.
  - To edit the label, enter changes in the label field.
  - To change the capacity, enter it and select a new unit of measure, if necessary.
3. Click **Submit**.  
The new job is added to the **Jobs** page.

## Managing shares and exports

Shares enable file sharing in Windows and exports enable file sharing in Linux.

### Shares and exports inventory

Access the inventory of shares and exports in the detail page for a storage system to view information about existing shares and exports in a tile or list view.

Use this page to add, edit, and delete shares and exports. You can also access related resources.

The following actions are available:

- To add a share or export, click the plus sign (+) to open the Create Shares/Exports page.
- To delete a share or export, select a tile and click Delete.
- To edit a share or export, select a tile and click Edit to open the Update Export page or the Update Share page.
- Click File System label in a tile to open the detail page for the file system where the share or export was created.
- Click VFS label in a tile to open the Virtual File Server detail page where the file system was created.

## Creating shares and exports

Create shares and exports to offer storage capacity to users.

### Procedure

1. Access the **Create Shares/Exports** page by clicking the plus sign (+) on the **Shares/Exports** page.
2. Enter a **File System Path** and a **Share/Export Label**.
3. Select a **File System**.
4. Create a share by selecting **Windows** or create an export by selecting **Linux**.
5. Click **Submit**.  
A job to create the share or export is added to the **Jobs** page.

## Export details

Access the detail page for an export to review internal and external paths and to edit the export.

The following controls are available:

- Delete the export by clicking Delete.
- Edit the export by clicking Edit to open the Update Export page.
- Access the file system where the export was created by clicking File System.
- Access the virtual file server where the file system was created by clicking VFS.

## Updating an export

You can update an export to change the file system path and access configuration.

### Procedure

1. Access the **Update Export** page by clicking **Edit** in an Export detail page.
2. (Optional) Enter a new path in the **File System Path** field.



3. (Optional) In the **Access Configuration** field, enter IP addresses, host names, or the NIS netgroups of the clients who are allowed to access the NFS export (up to 5957 characters).

If the system has been set up to work with a name server, you can enter the NIS netgroup to which the clients belong, or the client's computer name rather than its IP address (not case sensitive).

You can also specify the required flavors of NFS security in a colon-separated list using the option (sec=<list>).

The supported flavors are:

- none - Connect as a null user
- sys - The traditional security flavor used by NFS, users are not authenticated by the server
- krb5 - Kerberos authentication
- krb5i - Kerberos authentication with per-messaging integrity
- krb5p - Kerberos authentication with per-message privacy

For example: 10.1.\*.\*(sec=sys:krb5:krb5i)

See the mount-point-access-configuration man page for further information.

4. Click **Submit** to save any changes.  
A job is added to the **Jobs** page to update the export.

## Share details

Access the detail page for an share to review internal and external paths and to edit the export.

The following controls are available:

- Delete the share by clicking Delete.
- Edit the share clicking Edit to open the Update Share page.
- Access the file system where the export was created by clicking the File System label.
- Access the virtual file server where the file system was created by clicking the VFS label.
- Add an existing Account Domain user group to the share by clicking the plus sign (+) to open the Create Groups page.

## Adding existing account domain groups to a share

You can add an existing account domain group to a share. This enables you to change users permissions when they access the share.

### Before you begin

The account domain group and CIFS setup must already exist.

### Procedure

1. On the detail page for a share, click the plus sign (+) to open the **Create Groups** page.
2. In the **Group Name** field, type in a user group name from the account domain.
3. Choose permissions; **Full Control**, **Change**, or **Read**.
4. Click **Submit**.  
A job is started to add the group to the share.

## Updating a share

You can update a share to change the file system path, permissions, and access configuration.

### Procedure

1. Access the **Update Share** page by clicking **Edit** in a Share detail page.
2. (Optional) Enter a new path in the **Modify File System Path** field.
3. (Optional) In the **Access Configuration** field, enter IP addresses of the clients who can access the share (up to 5,957 characters allowed in this field).

What to type	Means	Example
Blank or * Partial addresses using wildcards.	All clients can access the share.	10.168.*.* Clients with matching addresses can access the share.
Specific addresses	Only clients with the specified IP address can access the share.	10.168.20.2
Specific address range	Only clients with an IP address within the specified IP address range (10.168.20.0 to 10.168.20.255) can access the share.	10.168.20.0/16
Partial addresses using wildcards	Clients with matching addresses can access the share.	10.168.*.*
<b>Permissions</b>		
<b>What to type</b>	<b>Permissions granted</b>	
(rw)	read-write	
(ro)	read only	



**Note:** The order in which you specify the entries is important. Take the following two lines:

- \*(ro)
- 10.1.2.38(rw)

The first grants read-only access to all clients, whereas the second grants read/write access to the specified client. The second line is redundant, however, as the first line matches all clients. You must transpose the lines to grant write access to 10.1.2.38. Examples:

- 10.1.2.38(ro) grants read-only access to the client whose IP address is 10.1.2.38.
- 10.1.2.0/24(ro) grants read-only access to all clients with an IP address in the range 10.1.2.0 to 10.1.2.255
- 10.1.\*.\*(rw) grants read-write access to all the matching clients.

4. (Optional) Select the supplied **Everyone** group and select permissions.
5. Click **Submit** to save any changes.  
A job is added to the **Jobs** page to update the share.

---

## Chapter 5: Data protection

Data protection refers to replication of volumes. Storage Advisor provides local and remote replication options.

### Data protection concepts

You can protect volumes with local replication or with remote replication.

- Local replication:

You can protect volumes locally on the same storage system and choose to protect a single volume, a group of volumes, or all volumes attached to a server.

- The Clone Now method creates a copy of a volume in a point in time. This method creates a full copy of a primary volume and automatically suspends the copy operation. Any further read-write operations of the primary volume will not be updated to the secondary volumes.
- The Snap method takes incremental snapshots of volumes based on a user-created schedule. The retention policy (maximum number of snapshots) is from 1 to 1024, based on user input. Once the retention policy is exceeded, the oldest snapshots are deleted when newer snapshots are created.



**Note:** When a user removes a storage system and adds it again, all the protected volumes using Clone Now will remain untouched, but any snapshot schedules will be suspended. The user will need to resume scheduling after adding the storage system.

- Snap on Snap is a snapshot that can support a cascaded configuration. They can be created inside or outside Storage Advisor. If they are created outside Storage Advisor, you cannot perform operations on the replication group, which is labeled "External".



**Note:** The cascaded configuration is not supported within Storage Advisor.

- Snap Clone is a full copy of a snapshot (P-VOL) and creates a real volume.



**Note:** You cannot create Snap Clone pairs using Storage Advisor.

- Remote replication: Use global-active device to help ensure reliability.

## Selecting volumes to protect

You can select a server, create volumes and attach them to the server, and then (optionally) protect the volumes.

As an alternative, you can create volumes separately and attach them to servers at a later time. After attaching volumes to servers, you can select volumes to protect.

### Procedure

1. To select volumes to protect, do one of the following:
  - Select a server, create volumes for the server and attach the volumes to the server.
  - Select a server to view volumes already attached to the server. You can filter for unprotected volumes.
  - On the dashboard, click **Storage Systems**, then click a storage system tile and click **Volumes** to open the **Volumes** page.
  - Open the detail page for any volume that is attached to a server.
2. Select volumes and then click **Protect** to open the **Protect Volumes** page with the list of selected volumes displayed.
3. Choose a type of data replication, **Clone Now** or .



**Note:** The **Clone Now** method is available for volumes that are already existing and attached to a server. It is not available when the create-and-attach workflow is used to create, attach, and protect volumes in a single page.

If you use the workflow provided to create, attach, and protect volumes, you can choose **None** as a data replication type to avoid protecting volumes.

## Protect volumes with local replication

### Protecting volumes by cloning

After creating and attaching volumes, you can implement data protection by creating a clone.

The Clone Now method can be useful if maintenance or testing of a volume is needed. You can clone the primary volume and perform testing when the clone is complete. If any data is lost, you can retrieve it from the secondary volume.

You can create up to three clones for a volume. Using Storage Advisor, you can do this performing the cloning operation on a set of volumes three times.



**Note:** The Clone Now method is available for volumes that exist and are attached to a server. It is not available when the create-and-attach workflow is used to create, attach, and protect volumes in a single page.

### Procedure

1. In the **Protect Volumes** page, select the volumes you want to protect and click **Clone Now**.
2. Choose whether to use **Consistency**.  
Using Consistency means that copy operations will run on all pairs in the group simultaneously. Consistency, schedule and retention policy are all filters for replication groups, so your choices may affect the availability of replication groups.
3. Select a replication group from the options in the **Replication Group Name** list or enter a new name.  
Up to 26 alphanumeric characters, and also hyphens (-) and underscores (\_), are allowed. Spaces are not allowed.
4. Click **Submit** to clone the volumes.

### Result

A job is created and a summary message displays.

## Protecting volumes by creating snapshots

After creating and attaching volumes, you can implement data protection by creating incremental snapshots.

You can use the Snapshot method if you don't need continuous copying but want to schedule the copy depending on expected changes in the data.



**Note:** For volumes on the following storage systems, you can create snapshots by accessing Storage Advisor Embedded: VSP F350, F370, F700, F900 and VSP G350, G370, G700, G900.

The snapshot creation process creates the secondary volume on a snap pool. If there is more than one snap pool, the least-utilized snap pool is used.



**Note:** If you want to create snapshots outside of Storage Advisor for a volume that is in Storage Advisor, use a new snapshot group.

### Procedure

1. In the **Protect Volumes** page, select the volumes you want to protect and click **Snapshot**.
2. Enter a number from 1 to 1024 in the **Snapshot Retention Policy (Max 1024)** field to specify the number of snapshots to be created.  
When the specified number of snapshots is reached, older snapshots will be deleted as new ones are added. The maximum number of snapshots that can be retained is 1024.

3. You can enable **Consistency** to perform data protection on all pairs in the group simultaneously.

Consistency acts as a filter for replication groups, so your choice may affect the availability of replication groups.

4. Set an hourly, daily, weekly, or monthly schedule. A volume cannot have more than one schedule. The schedule is based on UTC time.
  - **Hourly:** Select a start time in minutes after the hour, and the number of hours between snapshots to start creating snapshots at the selected time and interval.
  - **Daily:** Select a start time, available in five minutes increments, to start a snapshot every day at the selected time.
  - **Weekly:** Select a start time and a day to create a snapshot every week at the selected date and time. You can select more than one day to create more than one weekly snapshot.
  - **Monthly:** Select a start time and the day of the month (from 1 to 31) to create a snapshot once a month at the selected day and time.
5. In **Volumes to be Protected**, select a **Replication Group** for each volume or select **Use New** and enter a name for the new replication group in the **Replication Group Name**. Up to 26 alphanumeric characters, also hyphens (-) and underscores (\_), are allowed. Spaces are not allowed.
6. (Optional) Select the pool from the list of available pools. The default selection is **Auto Selected**, which means that Storage Advisor selects the best pool based on utilization and tier requirements.

If you choose a Thin (HDP) pool or a Snap (HTI) pool, the replication technology used will be Snap on Snap, unless there is already a Snap volume created in an earlier version of Storage Advisor. In that case, the replication technology used will continue to be Snap.
7. Click **Submit**.

### Result

A summary message is displayed and snapshots are created according to the schedule. The replication group can be viewed on the Replication Groups page.

## Protect existing volumes with high availability

You can protect existing volumes with high availability.

### Procedure

1. Access the **Volumes** page and select one or more attached volumes. They cannot belong to different VSMs. Select **Protect Volumes with High Availability**.

**Protect Volumes with High Availability**

Attach Settings | Select Secondary Servers | Protect Settings | Configure Primary Site | Configure Secondary Site

**STORAGE SYSTEM**  
410209

**VIRTUAL STORAGE MACHINE ID**  
425207-VSPF400-F600andVSPG...

**HOST MODE**  
AutoSelect

**HOST MODE OPTION**  
40 - VVol expansion, 73 - Support Option for WS...

**LUN ALIGNMENT**  
Yes No

**AUTO CREATE ZONE**  
Yes No

**ALUA ENABLED**  
Yes No

**Primary Servers related to selected Volumes**

SERVER NAME	SERVER ID	OS TYPE	ATTACHED VOLUME IDS
win9121	1	Windows EX	804 (00:03:24)

Cancel Next

- The **Host Mode** is set by default to the server operating system. You can make a selection if needed.

The server OS Type is provided when the server is added to Storage Advisor.

- The prepopulated **Host Mode Option** will depend on the **Host Mode** selection. The default Host Mode Option can be changed manually.

Default values are set only for **VMWARE EX** and **WIN EX** host modes. The default for all other Host Modes is none.

Storage Advisor identifies all host groups containing any of the server WWNs. If all of those host groups have the same host mode and host mode options, those settings are prepopulated with the same settings in the host groups.

- Select the **LUN Alignment**.

By default, Storage Advisor uses the LUN number that is common to the servers. If attachment is to only one server, this setting has no effect.

- The **Auto Create Zone** is set to **No** by default. You can set it to **Yes** to automatically create zones.


- ALUA Enabled** is set to **Yes**. If it is set to **No**, you must rediscover volume or restart the OS after job completion.

- Click **Next** to select secondary servers, if applicable.

- Click **Next** to choose a secondary storage system and replication group, and quorum disk.



9. In the **Protect Volumes** panel, select a secondary storage system.
10. Choose whether to use an existing replication group.
11. **Consistency** is set to **Yes** and cannot be edited. Using consistency means that copy operations will run on all pairs in the group simultaneously.
12. Select a replication group from the options in the **Replication Group** list or enter a new name. Up to 26 alphanumeric characters, and also hyphens (-) and underscores (\_), are allowed. Spaces are not allowed. If you select an existing replication group, the **Storage Pool of Secondary Storage System for S-Vol** and **Quorum Disk** are selected automatically.
13. Select the pool to use for S-Vols and select a quorum disk.
14. Click **Next** to configure the primary site.
15. In the **Configure Primary Site** panel, you can view the path of the primary server. If you need to change it, you will need to edit the LUN path before applying data protection.




16. Click **Next** to configure ports in the secondary storage system to the server in the primary site, and to the server in the secondary site, if there is one.
17. Click **Submit** to create a job to protect volumes.
18. You can monitor the job in the **Jobs** page.



**Note:** If the job does not complete successfully, access Data Instance Director to remove the related resources (**Block Host Node**, **Policy**, and **Data Flow**) with the same name as the selected replication group. When using an existing replication group, remove added **P-Vol** from **Block Host Node**.

To edit a Block Host Node created by Storage Advisor in Data Instance Director, specify LDEV IDs in decimal format per line and not in hex format or range format.



## Viewing replication groups

Storage Advisor enables you to view all replication groups in a single page.

You can also access replication details for a volume to view and manage all replication group membership and volume pairs.

Storage Advisor detects and displays all volume pairs, whether or not they were created in Storage Advisor.


Replication groups apply the policies that control how volumes are replicated. Their parameters include:

- Type of technology:
  - High Availability for remote replication.
  - For local replication:
    - Snap on Snap
    - Snap Clone
    - Snap
    - Clone
- Whether consistency is used
- Snapshot schedule
- Snapshot retention

Replication groups are created when volumes are replicated.

## Replication groups inventory

Access the inventory of replication groups from the detail page for a storage system.



This page enables you to view all replication groups, sorted by technology:

- Snap on Snap
- Snap Clone
- Snap
- Clone

Replication groups created outside Storage Advisor are listed as External.

You can view all volume pairs, including those created outside of Storage Advisor.



**Note:** Replication group operations other than Restore are not available for External replication groups. If a copy group is renamed outside Storage Advisor, the replication group will become External. Copy groups cannot be renamed using Storage Advisor.

Use this page to:

- View replication policies applicable to a volume and all S-VOL details.
- View all replication policies and all volume pair details.
- Suspend or resume a snapshot schedule.  
Data replication can be suspended and resumed. Data will be missing for the period of suspension.
- Suspend or resume a clone.  
Data replication can be resumed to update cloned data and then suspended to keep a point-in-time full copy.
- Remove a volume from a replication policy. Delete a replication group to remove the policy from all volumes in the group.
- Restore a volume pair by restoring a secondary volume to a primary volume.

The following actions are available after selecting a replication group:

- Edit the replication group by clicking Edit to open the Edit Replication Group page and edit the label or remove volumes from the replication group.
- Suspend the replication group by clicking Suspend Replication Group. You cannot suspend a replication group that is in COPY status.
- Resume the replication group by clicking Resume Replication Group.
- Delete the replication group by clicking Delete.

To view volume pair details, expand one or more replication groups.

- Access detail pages for each P-VOL and each S-VOL by clicking a P-VOL ID or an S-VOL ID in the expanded view of a replication group.
- Before using the Restore function, stop all I/O activity to the volume. To restore a volume pair, select it and click Restore Volume Pair.



**WARNING:** The Restore function will overwrite the volume with backup data. The data on current volume will be destroyed.

### Opening the Local Replication page in Storage Navigator

Click Open the Local Replication page in Storage Navigator to view the replication groups information for clones and snapshots.

For more information, refer to the Storage Navigator online help.



**Note:** Any changes you make in Storage Navigator may not be reflected in Storage Advisor for a few minutes.

## Editing replication groups

You can edit a replication group to adjust the schedule for snapshots or to remove volumes from the replication group.



**Note:** External replication groups cannot be edited. These include volume pairs that are created outside Storage Advisor.

### Procedure

1. Access the **Edit Replication Group** page from the **Replication Groups** page.
2. You can edit the following:
  - Name
  - Comments
  - For snapshots, the schedule and number of snapshots. The schedule is based on UTC time.
  - (Optional) Select the pool from the list of available pools. The default selection is **Auto Selected**, which means that Storage Advisor selects the best pool based on utilization and tier requirements.

3. To remove a primary volume from the replication group, select the corresponding row. You can choose whether or not to remove the corresponding secondary volume.
4. Click **Submit**.  
A job is added to the Jobs page to apply the changes to the replication group.

## Volume details

Access volume details in one of these ways:

- From the dashboard by clicking Storage Systems, and then click a storage system tile. Click Volumes to open the Volumes page and then click a volume in the list or tile view.
- On the detail page for a pool, click a volume in the list or tile view.

The Volume detail page exposes pool details including Pool ID, type and tier of the pool.

The Provisioning Status can be any of the following:

- Attached: the volume is attached to a server.
- Unattached: the volume is not attached to a server.
- Unmanaged: the volume has only a LUN path associated. For example, a volume may be attached to a server that is not known to Storage Advisor.

Details for protected volumes also include details of all replication groups to which the volumes belong.

On a volume detail page, you can do the following:

- Attach the volume to a server by clicking Attach Volumes.
- Edit the volume configuration by clicking Edit to open the Update Volume window.

If a primary volume is unprotected, you can expand the capacity. When you click Submit, a notification informs you that a job has started to expand the volume. Secondary volumes cannot be expanded.

- Delete the volume.



**Note:** If deduplication or compression has been enabled on the volume and the volume has data, it cannot be deleted in Storage Advisor. Access Storage Navigator to delete the volume.

- Protect the volume by clicking Protect Volumes to open the Protect Volumes page.
- Unprotect a volume by clicking Unprotect Volumes.
- Expand any or all replication groups to which the volume belongs and view details of the volume pairs. In the table, you can click an S-Vol ID to open the detail page for the secondary volume.

- Restore a secondary volume to a primary volume by selecting the pair and clicking Restore Volume Pair.
- Perform the following operations on a replication group:
  - Edit the replication group by clicking Edit.
  - Suspend the replication group by clicking Suspend Replication Group.
  - Resume the replication group by clicking Resume Replication Group.
  - Delete the replication group by clicking Delete.



**Note:** Replication group operations are not available for "External" replication groups. These are volume pairs that were created outside Storage Advisor.

## Global-active device

Storage Advisor supports the display of high availability as a replication technology when the following conditions are met:

- GAD has been configured on the storage system.
- GAD pairs have been created on the storage system.

GAD pairs display in Virtual Storage Machines, Volumes inventory, and Volume detail pages as high availability (HA).

Global-active device enables you to create and maintain synchronous, remote copies of data volumes.


## Virtual storage machines

View the virtual storage machines (VSMs) in the GAD configuration to check details and view any alerts.

Access the **Virtual Storage Machines** page from the Storage Advisor dashboard.

To view details for a virtual storage machine, click a tile on the **Virtual Storage Machines** page.

The **Virtual Storage Machine** detail page includes P-VOLs and S-VOLs in each pair, as well as the pair status and the storage systems for each pair.





---

## Chapter 6: Provisioning for high availability

You can use Storage Advisor to provision P-Vols and S-Vols and create high availability pairs. High availability is supported by global-active device technology.

To set up high availability, configure a virtual storage machine (VSM) in a secondary storage system, and optionally, in a primary storage system. A virtual storage machine can be configured using the actual information of the primary storage system, and the global-active device primary and secondary volumes are assigned the same virtual LDEV number in the virtual storage machine. This enables the server to see the pair volumes as a single volume on a single storage system, and both volumes receive the same data from the server. Alternatively, you can use virtual model and virtual serial numbers.

### Prerequisites to provisioning for high availability

Review the conditions required to provision for high availability.

Make sure that the following conditions are met before provisioning for high availability:

- Data Instance Director v6.6.1 or later is registered in Storage Advisor.
- The registered Storage Advisor satisfies the following conditions
  - Both primary and secondary storage systems are registered with Data Instance Director.
  - global-active device licenses for both primary and secondary storage systems are installed in Data Instance Director.
- At least one Fibre Channel server must be registered.
- The primary and secondary storage systems must have the following configured:
  - A quorum disk. (The same disk and ID should be assigned in each storage system.)
  - Remote paths , which should be configured bidirectionally.
    - If the VSM in the primary storage system is using the meta\_resource, a VSM with at least one undefined host group must be configured in Storage Advisor for the secondary storage system.
    - If the VSM in the primary storage system is not using the meta\_resource, a VSM with at least one undefined volume and one undefined host group must be configured for the primary storage system and, a VSM with at least one undefined host group must be configured for the secondary storage system in Storage Advisor.
- Make sure that both primary and secondary storage systems:
  - Are onboarded in Storage Advisor.
  - Have at least one Fibre port.
  - Have global-active device licenses.
  - Firmware version 80-06-6x or later is required for XP7 models.
  - Firmware version 83-04-01-x0 or later is required for VSP G200, G400, G600, G800 and VSP F400, F600, F800 models.
  - Have enough room to create volumes and remote pairs including CTG.
  - Have a THP or Smart pool with enough capacity.

## Register Data Instance Director in Storage Advisor

You can use Storage Advisor to register Data Instance Director settings.


### Before you begin

Data Instance Director is installed. The user with permissions to perform pair management operations is identified.

### Procedure

1. From the **Settings** menu, click **Data Instance Director Settings**.

2. Under **Connection Information**, enter the IP address of the Master node. The port number of the Master node displays automatically.
3. Under **Account Information**, enter the user name and password of the Data Instance Director user who can perform pair management operations for high availability.
4. Click **Test Connection** to verify that you connected to the Master node successfully.
5. Click **Submit**.



The screenshot shows the 'Data Instance Director Settings' window. It contains two main sections: 'Connection Information' and 'Account Information'. In the 'Connection Information' section, the 'IP Address of Master Node' is set to '10.76.49.230' and the 'Port number of Master Node' is '443'. In the 'Account Information' section, the 'Username@AuthenticationSpace' is 'Administrator@master' and the 'Password' field is labeled 'Password of the user'. Below these fields are two buttons: 'Update DID Profile' (highlighted in green) and 'Unregister DID Profile' (disabled). A 'Test Connection' button is located at the bottom left. At the bottom right of the window are 'Cancel' and 'Submit' buttons.

## Create, attach, and protect volumes with high availability

Storage Advisor allows you to create, attach, and protect volumes in a single page.

### Before you begin

Register Data Instance Director in Storage Advisor.

### Procedure

1. Click **Servers** on the dashboard to open the **Servers** page or navigate to the detail page for a server.
2. Select a server, then select **Create, Attach and Protect Volumes with High Availability**.

3. Configure volumes for the specified storage system.

You can switch to another storage system by using the drop-down **Storage System** list. If you want to add the volume to a virtual storage machine, use the **Virtual Storage Machine** list. If you don't choose a VSM the meta-resource group will be used.

- Select the number of volumes.
- Enter the volume label and select a suffix for it.
- Select the size.
- Select the volume unit: **GiB**, **TiB**, or **PiB**.
- Select the pool type: **Thin** or **Tiered**.
- For a Thin pool, select the tier: **Platinum**, **Gold**, **Silver**, or **Bronze**.

If the storage system has available capacity from external storage, you can also select the **External** tier.

- (Optional) Select the pool from the list of available pools. The default selection is **Auto Selected**, which means that Storage Advisor selects the best pool for provisioning the volume based on utilization and tier requirements.

4. If desired, select a type of **Capacity Saving: Compression** or **Deduplication and Compression**.



**Note:** Capacity saving can be set for volumes based on tiered pools only for VSP F1500, VSP G1000, and VSP G1500 models with microcode version 80-05-4x or later.



**Note:** If you choose **Deduplication and Compression** and later want to update the volume to **Compression** you must first disable **Capacity Saving**.

- When you have made your choices, click the plus sign (+) to add the volume row to the list of volumes that will be created. Add more rows as needed.
- Click **Next** to choose attachment settings.

## Attach volumes and select secondary servers


### Before you begin

- In the Settings menu, access the Data Instance Director Settings page and register Data Instance Director .
- Make sure that a quorum disk is available.
- Make sure that a virtual storage machine is available unless you want use the meta-resource group of the primary storage system. The virtual storage machine you select must have one or more undefined resources available.

### Procedure

1. The **Host Mode** is set by default to the server operating system. You can make a selection if needed.  
The server OS Type is provided when the server is added to Storage Advisor.
2. The prepopulated **Host Mode Option** will depend on the **Host Mode** selection. The default Host Mode Option can be changed manually.  
Default values are set only for **VMWARE EX** and **WIN EX** host modes. The default for all other Host Modes is none.  
Storage Advisor identifies all host groups containing any of the server WWNs. If all of those host groups have the same host mode and host mode options, those settings are prepopulated with the same settings in the host groups.
3. Select the **LUN Alignment**.  
By default, Storage Advisor uses the LUN number that is common to the servers. If attachment is to only one server, this setting has no effect.
4. The **Auto Create Zone** is set to **No** by default. You can set it to **Yes** to automatically create zones.
5. Leave **ALUA** set to **Enabled** if you want to set preferred paths.

- Click **Next** to proceed to the **Select Secondary Servers (Optional)** panel.




- Optionally, select a secondary server and click **Next** to proceed to the **Protect Volumes** panel.

## Select volume protection options

Select a secondary storage system and other options.

### Procedure

- Select a secondary storage system.
- Choose whether to use an existing replication group.




3. **Consistency** is set to **Yes** and cannot be edited. Using consistency means that copy operations will run on all pairs in the group simultaneously.
4. Select a replication group from the options in the **Replication Group** list or enter a new name. Up to 26 alphanumeric characters, and also hyphens (-) and underscores (\_), are allowed. Spaces are not allowed. If you select an existing replication group, the **Storage Pool of Secondary Storage System for S-Vol** and **Quorum Disk** are selected automatically.
5. Select the pool to use for S-Vols and select a quorum disk.
6. Click **Next** to configure the primary site.

## Configuring connections to the primary and secondary sites

Configure the primary and secondary sites to complete high availability provisioning.

### Procedure

1. In the **Configure Primary Site** panel, connect ports in the primary storage system to the server in the primary site and to the server in the secondary site, if there is one. You can configure preferred and unpreferred paths.



2. Click **Next** to configure ports in the secondary storage system to the server in the primary site, and to the server in the secondary site, if there is one.
3. Click **Submit** to create a job to create volumes, attach to servers and set up data protection.
4. You can monitor the job in the **Jobs** page.



**Note:** If the job does not complete successfully, access Data Instance Director to remove the related resources (Block Host Node, Policy, and Data Flow) with the same name as the selected Replication Group.

When using an existing **Replication** group, remove added **P-Vol** from **Block Host Node**.

To edit a Block Host Node created by Storage Advisor in Data Instance Director, specify LDEV IDs in decimal format per line and not in hex format or range format.

Dashboard / Nodes > / fk\_rg12112018\_qd0 / Edit

Edit Node - Hitachi Block Host 'fk\_rg12112018\_qd0'

### Specify Logical Devices

Enter Logical Devices using any of the following formats:

- LDEV\_ID - for a single logical device, e.g., 100, 0x10
- LDEV\_ID-LDEV\_ID - for a logical device range, e.g., 200-299, 0x01-0x0F
- Host Group ID - for all logical devices within the host group, e.g., CL1-A-0, CL10-A-0

**Logical Devices**

169  
177  
139

One entry per line.

Cancel Previous Next



## Chapter 7: Manage virtual storage machines

Storage Advisor allows you to create virtual storage machines and add volumes and host groups to them.

You can also add defined and undefined resources to an existing virtual storage machine and remove defined and undefined resources from an existing virtual storage machine.


### Creating virtual storage machines

You can use Storage Advisor to create virtual storage machines.

Each virtual storage machine must have a model number and a serial number. After assigning those, you can add volumes and host groups.

#### Procedure

1. On the dashboard, click **Virtual Storage Machines** and then click the plus sign (+) on the **Virtual storage machines** page.




2. On the **Create VSM** page, select the storage systems you want to use.
3. Choose whether to use the model and serial number of one of the selected storage systems for the new virtual storage machine.
  - If you choose **YES**, the entire meta\_resource group of the storage system will be the virtual storage machine.
  - Click **NO** to select a virtual model and a virtual serial number.

4. Click **Next** to add volumes to the virtual storage machine.  
You can add volumes from any or all selected storage systems, or skip this step and add volumes later.
5. Click **Next** again to add host groups. Add host groups from one storage system at a time and click the plus sign (+) to add them to the list.
6. Click **Submit** to create a job to add the virtual storage machine.

## Virtual storage machine inventory

Access the Virtual Storage Machines page to view all virtual storage machines and perform operations on them.

Click **Virtual Storage Machines** on the dashboard to open the **Virtual Storage Machines** page.



The following actions are available on this page:

- Select one or more virtual storage machines and click **Delete** to permanently remove them.  
All resources will be removed from the virtual storage machine and the virtual storage machine will be deleted. Removed resources will be moved to the meta resource group. A virtual storage machine with attached volumes or GAD pairs cannot be deleted.
- Select a virtual storage machines and click **Remove VSM** to remove undefined resources from the virtual storage machine.
- Select a virtual storage machines and click **Add VSM** to open the menu and do one of the following:
  - Click **Move Volumes to a VSM** to open the **Move Volumes to a VSM** page and move volumes from a storage system to a virtual storage machine.
  - Click **Add Resources to a VSM** to open the **Add Undefined Resources to VSM** page and add resources from one or more storage systems to a virtual storage machine.

## Remove undefined resources from a virtual storage machine

You can remove undefined resources if you no longer need them.

### Procedure

1. On the **Virtual Storage Machines** page, select a virtual storage machine and click **Remove VSM**.


2. On the **Remove Undefined Resources from VSM** page, select a storage system from the menu and enter the number of volumes to be removed.
3. Click the plus sign (+) to display your selections in the lower half of the page. Add more selections if needed.
4. Click **Next**.
5. Remove host groups using the procedure as for volumes.
6. Click **Submit** to start a job to remove the undefined resources.

## Move volumes to a virtual storage machine

You can move defined volumes from a storage system that is in a virtual storage machine to the virtual storage machine.

### Procedure

1. To access the **Move Volumes to a VSM** page, select a virtual storage machine on the Virtual Storage Machines page.




2. Select **Add VSM** and click **Move Volumes to VSM** in the menu.
3. Select a storage system in the **Storage System** menu to display the available volumes.
4. Select volumes to be moved and click **Submit** to start a job to move the volumes.

## Add undefined resources to a virtual storage machine


You can add additional resources to a virtual storage machine.

### Procedure

1. To access the **Add Undefined Resources to VSM** page, select a virtual storage machine on the **Virtual Storage Machines** page.
2. Select **Add VSM** and click **Add Resources to a VSM** in the menu.



3. Optionally, select one or more storage systems and click **Next** to add volumes.



4. For each storage system you selected, enter the number of undefined volumes you want to add in the **Number of Volumes** field. Click the plus sign (+) to add your selections to the lower panel. When you are finished adding selections, click **Next** to add host groups.
- At least one undefined volume must remain in each storage system.
5. Add host groups for each required storage system and port combination. Click the plus sign (+) to add the selection to the lower panel.
6. When all selections are complete, click **Submit** to start a job to add the undefined resources.

## Virtual storage machine details

Review the details for a single virtual storage machine.

Access the **Virtual Storage Machine** detail page from the **Virtual Storage Machines** inventory.



The following actions are available:

- Select one or more storage systems and click **Delete** to remove it from the virtual storage machine.
- Click **Open GAD Pairs** to view the global-active device pairs on this virtual storage machine.
- Click a storage system in the list or tile view to view details of volumes and hosts groups in this virtual storage machine in the **Physical Storage System** page.
- Click **Go to Storage System Details** to view all resources and storage system information.

## Physical storage system details

Perform a variety of operations on the volumes belonging to a storage system that is in a virtual storage machine.

In the **Virtual Storage Machine** detail page, click a storage system ID to open the Physical Storage System page.



The following actions are available on this page:

- Under **Host Group** click **View more details** to open the **Physical Storage System Host Group** page and view details of ports in the host group.
- Click the plus sign (+) to add volumes on the Create Volumes page.
- Click a volume to view details and attach, update or delete the volume.
- Select a volume and click **Edit** to update the volume by editing the name or updating the Capacity Saving setting. If the volume is unprotected you can also expand the capacity.
- Select one or more volumes to perform one of the following actions:
  - To delete volumes, click **Delete**. When you delete a volume, it is de-provisioned and removed from the storage system.



**Note:** If deduplication or compression has been enabled on the volume and the volume has data, it cannot be deleted in Storage Advisor. Access Storage Navigator to delete the volume.

- To attach existing volumes to one or more servers on the Attach Volumes page, click **Attach Volumes**.
- To detach volumes from servers, click **Detach Volume**.
- To apply data protection on the Protect Volumes page, click **Protect Volumes**.
- To unprotect a volume, select it and click **Unprotect Volumes**.



**Note:** A volume in an "External" replication group cannot be unprotected.

- To restore a secondary volume to the primary volume, click **Restore** to open the Restore Volume page.
- To attach the volume to a storage system to prepare for volume migration, click **Attach to Storage**.
- To migrate volumes, click **Migrate Volumes**.
- To detach volumes from target storage, click **Detach From Target Storage**.
- To shred volumes that have been migrated, click **Shred Volumes**.
- To remove defined volumes from a virtual storage machine, click **Remove Volumes**.



---

## Chapter 8: Migrate volumes

Volume migration is moving a volume and its associated data from a source location to a destination.


### Volume migration workflow

Storage Advisor provides an end-to-end workflow for migrating volumes from one pool to a different pool within one storage system (internal migration) and an end-to-end workflow for migrating volumes from one storage system to another (external migration).

Volume migration involves moving data from a set of source volumes to a set of destination volumes. For example, you can migrate data when your volume performance decreases or your environment changes. When relocating data based on the results of performance monitoring for volumes being used by servers and applications, or when migrating data from an old storage system to a newly set-up storage system, the data in multiple volumes can be migrated to other volumes.

For internal migration, see the following: [Migrating volumes \(on page 125\)](#),

The following figure shows the high-level workflow of volume migration in Storage Advisor.



External volume migration supports two options; in each case the volumes must be attached to the target storage as the first step in migration:

1. Both the source and target storage systems are managed in Storage Advisor.
2. The source storage system is one that is not supported by Storage Advisor. In this case, the volume cannot be attached using Storage Advisor.

Volume virtualization is a required step in external migration. It creates external parity groups, creates external volumes on the external parity groups, and attaches the volumes. It creates a pointer to the original volume from the target storage system.

## External migration of volumes over 4TiB

To migrate an external volume greater than 4TiB, first create a data direct mapping (DDM) pool.

The DDM pool is used to create the external volume. You can delete the extra pool during the unvirtualization phase,

DDM pools are flagged **DDM Enabled: YES** in the **Pools** page and in the pool details pages.


To add a DDM pool, navigate to the Advanced tab of the Create Pool page and select Yes under Intend to enable DDM?

## Attaching volumes to storage when the source is managed in Storage Advisor (for external migration)

As a part of external volume migration with the source storage system managed in Storage Advisor, the volumes must first be attached to the target storage system.

### Procedure

1. On the Storage Advisor dashboard, click **Storage Systems** to see the inventory of storage systems and capacity information.
2. To select volumes to attach to storage, do one of the following:
  - Select a storage system and click **Volumes** to see the configured volumes for the storage system.
  - Click **Servers** on the dashboard and select a server.
3. Select one or more volumes and click **Attach to Storage**.



4. Select the protocol to display the ports for that protocol.
5. Click a source storage port and then click a target storage port to create a path.
6. Click **Submit**.

### Result

A job is started in Storage Advisor to create a path from the volume to the target storage system.

## Discovering external storage

Discover external storage on the target storage system so you can virtualize volumes.

**Before you begin**

Volumes must be attached to the target storage system.

**Procedure**

1. Open the **Storage System** page for the target storage system.
2. Click **Ports** and select the ports that are attached to the source storage system.
3. Click **Discover External Storages**.

**Next steps**

Discover and virtualize volumes.

## Discovering and virtualizing volumes


When using external migration, volumes must be virtualized before they can be migrated.

**Before you begin**

Perform the steps to attach volumes to storage and discover external storage.

**Procedure**

1. Navigate to **External Volumes** on the target storage system.
2. Click the plus (+) sign to open the **Create External Volumes** page.  
A list of discovered LUNS appears.
3. Select the discovered LUNs and click **Next**.
4. Select servers and click **Next**.
5. Click a server and then click a port to create a path between server and port.



6. Click **Submit**.

### Next steps

1. After virtualization completes successfully, go to the server and locate and mount the newly attached external volume. This changes the I/O from the older volume(LUN) to the new LUN. This action is required before data can be migrated and will ensure that no data is lost in the process.
2. Select volumes on the **External Volumes** page and migrate them.

## Migrating volumes

You can select volumes and migrate them immediately or on a schedule.

You must be either a storage administrator to migrate volumes.

### Before you begin

#### For internal migration ensure the following:


- All selected volumes belong to a single storage system that is managed in Storage Advisor.
- All selected volumes will be migrated to a different pool of the same storage system.
- All selected volumes are attached to servers.
- The volumes are not protected. However, a clone pair can be migrated if the P-VOL status is PSUS and the S-VOLs status is SSUS.
- The storage system has at least one eligible pool (Thin or Tiered) with enough space to migrate volumes.

#### For external migration, ensure the following:

- The target storage system must be onboarded in Storage Advisor.
- The source volumes must be virtualized and selectable as external volumes.
- The target storage system must have at least one eligible pool (Thin or Tiered) with enough space to migrate volumes.

### Procedure

1. For internal migration, navigate to one of the following to select volumes:
  - The Volumes page
  - The details page for a volume
  - The details page for a server
  - The details page for a pool
2. For external migration, navigate to the **External Volumes** page.
3. Select volumes to migrate and click **Migrate volumes**.




4. Select a pool that has enough space to migrate the volume and click **Next**.
5. Choose to **Migrate Now** or **Migrate Later**:
  - **Migrate Now** requires a **Migration Task Name**.
  - **Migrate Later** requires a **Migration Task Name**, a **Start Time**, and a **Start Date**. You can change the schedule or discard it after submitting the task.
6. Click **Submit** and confirm that you want to migrate the volume.

## Managing external volumes

Access the External Volumes page to add, migrate, or delete external volumes.

### Procedure

1. Navigate to the detail page for a storage system and click **External Volumes**.



2. On the **External Volumes** page, the following actions are available:
  - Click **Open the Logical Devices page in Hitachi Storage Navigator** to perform advanced migration operations in Storage Navigator.
  - To create external volumes, click the plus sign (+) to open the **Create External Volumes** page.
  - To migrate external volumes, select attached volumes and click **Migrate Volumes**.



**Note:** The **Assigned to Migration** filter can display which volumes are already part of a migration plan. If a volume status is **Yes (Unmanaged)** the volume is assigned for migration in other storage management tools.

## Managing migration tasks

Access the Migration Tasks page to modify or delete migration tasks, or to interrupt a migration.

### Procedure

1. Navigate to the detail page for a storage system and click **Migration Tasks**.

Migration Tasks						
<input type="checkbox"/> Select All      Interrupt Migration in Progress						
	ID	NAME	PAIR COUNT	SCHEDULED DATE	STATUS	JOB START
>	110	VolumeMigration-...	16	Apr 21, 2018 8:42:...	N/A	N/A
>	114	VolumeMigration-...	120	Apr 26, 2018 2:42:...	Scheduled	N/A
>	117	VolumeMigration-...	16	Apr 26, 2018 5:42:...	Scheduled	N/A
>	112	VolumeMigration-...	120	Apr 26, 2018 7:42:...	Scheduled	N/A
>	113	VolumeMigration-...	32	Apr 27, 2018 8:42:...	Scheduled	N/A
>	115	VolumeMigration-...	64	Apr 27, 2018 7:42:...	Scheduled	N/A
>	111	VolumeMigration-...	16	Apr 29, 2018 2:42:...	Scheduled	N/A
>	119	VolumeMigration-...	120	N/A	N/A	N/A
>	118	VolumeMigration-...	16	N/A	N/A	N/A

2. On the **Migration Tasks** page you can perform the following actions:
  - Select a scheduled task and click **Edit Migration Task** to open the **Edit Migration Task** page where you can update the pool and the schedule.
  - Select an in-progress migration task, click **Interrupt Migration in Progress** and confirm that you want to stop the migration. The migration cannot be restarted once it has been interrupted.
  - Select a migration task that is not in progress, click **Delete Migration Task** and confirm that you want to delete it.

For more information about deleting migration tasks, see [Deleting a volume migration task \(on page 129\)](#).


## Editing a volume migration task

Update the pool or the schedule for a planned migration.

If a volume migration has been scheduled but is not in progress you change the selected pool or schedule.

### Procedure

1. On the storage system detail page, click **Migration Tasks**.
2. On the **Migration Tasks** page, select a scheduled task and click **Edit Migration Task**.



3. Choose a different pool if desired and click **Next**.
4. In **Task Settings**, you can change the schedule or choose to migrate immediately.

## Interrupting an in-progress volume migration

You can interrupt a volume migration that is in progress.




The length of time for volume migration depends on the number of volumes that will be migrated and the protocol. Fibre Channel is faster than iSCSI. If it is taking too long, you can interrupt it. Once the migration is interrupted, you will need to discard the task by deleting the migration task. If you want to retry, you will then need to create a new migration task.

### Procedure

1. Click **Migration Tasks** on the storage system details page.
2. Select a migration task.
3. To stop a task in progress, click **Interrupt Migration in Progress** and confirm that you want to stop the migration.

## Workflow for clean-up after migration

The following diagram shows the workflow for clean-up after migration.



## Deleting a volume migration task

You can delete a migration task that is not in-progress.

### Procedure

1. Navigate to the detail page for a storage system and click **Migration Tasks**.
2. On the **Migration Tasks** page, select a migration task and click **Delete Migration Task**.
3. Confirm that you want to delete the migration task.

## Unvirtualizing external volumes

After you have finished migration, you have an external link to an old volume that you no longer need. Unvirtualizing volumes is cleaning up the environment after migration.

Unvirtualization deletes the external paths and logical devices created during the virtualization flow. It also deletes the external parity groups and the paths from the external parity group to the source storage system. Unvirtualization detaches the external volume, removes the zone, if applicable. It also deletes the external volume, external parity group and paths. Unvirtualization is required to restore the system back to its original state.

### Procedure

1. To unvirtualize, select the external volumes in the details page for the storage system .
2. Click the trash can. This also deletes the external parity groups and the paths from the external parity group to the source storage system.

## Detaching volumes from storage

Detaching volumes from storage means removing the connection between source and target storage systems.

Detaching volumes from storage deletes the paths from the source storage system to the target storage system. The paths were set when volumes were attached to storage. Detaching volumes from storage is required to restore the system back to its original state.

### Procedure

1. Navigate to **Volumes**.
2. Select the volume.
3. Click **Detach from Target Storage**.

## Shredding volumes

After you have completed volume migration, you can erase data in the source volumes by shredding.

You can shred source volumes that were used in either internal or external migration. To shred volumes that were used for external migration, the volumes must belong to a storage system that is managed by Storage Advisor. For external storage systems (such as third party storage systems), the source volumes must be shredded in the third party storage management tool.

You can shred volumes using a shredding pattern that you create or a pre-defined pattern. You can view and find the volumes that are shredding and you can interrupt (stop) shredding operations.

You must be a storage administrator to perform shredding.

Storage Advisor allows you to interrupt (stop) the running shredding operations. If you want to perform an urgent operation while shredding is running, first interrupt the shredding job and then execute the operation.

### Before you begin

Ensure that:

- Volumes use a custom-made shredding pattern created by you or a pre-defined pattern.
- The volumes are unattached and are not snapshots.
- The volumes do not have capacity savings.
- Up to 7 passes are specified.
- The storage systems have a physical connection/zone between them.

### Procedure

1. From the dashboard, click **Storage System**, click a storage system tile to open the detail page, and click **Volumes**.
2. Select volumes to be shredded.
3. Click **Shred Volumes**.

4. Choose **Basic** or **Advanced**. The **Basic** method performs one pass. Choose **Advanced** to select the number of passes and enter a pattern for each pass.

### Result

The volume has the status SHREDDING in the **Volumes** page.

---

## Chapter 9: Monitor block storage

Hitachi Storage Advisor supports monitoring of capacity, data protection, jobs, and hardware.

### Monitoring capacity

Monitor the capacity of block storage pools.

You can use Storage Advisor to monitor block storage capacity so you can tell when physical capacity usage is exceeding thresholds set for your pools.



**Note:** Capacity alerts for Snap (HTI) pools are not supported.

Alerts are represented by the number in the Capacity tile. If there is a checkmark, there are no alerts. A red circle represents an Error and a yellow triangle represents a Warning. Only the highest level of alert is shown, so a red circle can include Errors and Warnings if there is more than one level of alert. The Error threshold is set in the "Utilization Threshold (High)" field when the pool is created and the Warning threshold is set in the "Utilization Threshold (Low)" field.

Capacity Alerts for all storage systems are shown on the dashboard and on the Monitoring tab. Click the Capacity tile on the Monitoring tab to view the pools that have alerts. In the expanded carousel, click Pools to view alert details. The number of Capacity Alerts cannot be more than 1 because Storage Advisor monitors at the component level, which is pools.

The alert clearance process runs every 20 minutes for each storage system that has pools with errors. Alerts are only cleared when all pools with errors in the storage system return to normal state. For example, if there are 5 pools with errors in one storage system, then all alerts will display until all the pool alerts are cleared.

#### Procedure

1. Monitoring alerts display for the following resources:
  - All storage systems: If **Capacity Alerts** on the dashboard has a red circle or a yellow triangle, click it to open the **Monitoring** tab with the number of **Pool** alerts exposed in the **Capacity** carousel. Alternatively, you can click the **Monitoring** tab and then click the **Capacity** tile.
  - Storage systems inventory: This option also displays all capacity alerts. Click **Storage Systems** on the dashboard and if the **Capacity Alerts** tile has a red circle or a yellow triangle, click it to open the carousel in the **Monitoring** tab.

- Storage system detail: In the storage systems inventory, click a storage system tile. If the **Capacity Alerts** tile has a red circle or yellow triangle, click it to open the tile in the **Monitoring** tab and display the **Pool** alerts for the selected storage system.
  - Pool inventory: On the storage system inventory page, click a storage system tile to view resources for the storage system. Click **Pools**. Then click the **Capacity Alerts** tile to open the alerts carousel for the storage system pools in the **Monitoring** tab.
2. In the **Capacity** alerts carousel, click **Pools** to populate the table with details of the alerts.



**Note:** Ref Code mapping to trap descriptions is available in a file included with the ISO image.

### Next steps

If there are pools with alerts displaying the "Error" status, you can expand the pools to increase their capacity.

## Monitoring hardware

Monitor hardware devices to view and investigate warnings and critical alerts.

Storage Advisor monitors components in your storage systems and displays alerts on resource and storage system pages. You can also see how many components are in normal status.

Alerts are represented by a number in the Hardware tile or the Hardware Alerts tile. A red circle represents a critical alert and a yellow triangle represents a warning. Only critical alerts are shown unless there are no critical alerts, in which case warning alerts are displayed.

The alerts are received from the storage array. There is one alert per component type, for a maximum of eight.

The alert clearance process runs every 20 minutes for each storage system that has components with errors. Alerts are only cleared when all components of a given type with errors in the storage system return to normal state. The exception is disks, each of which can have alerts cleared, even if other disks remain in error. Alerts for ports and processors are cleared together, so alerts are cleared only when all ports and all processors are normal.

For example, if there are five fans with alerts in one storage system, they will be cleared only when each and every fan alert is cleared. However, for disks, each alert is cleared as and when disk alert clearance is available.

Storage Advisor monitors the following components:

- Disks
- Fans
- Batteries

- Cache
- Processors
- Power supplies
- Ports
- Shared memory

### Procedure

1. Hardware alerts display in the following pages. Alerts are displayed by type of component.
  - Dashboard: Click the **Hardware Alerts** tile or the **Monitoring** tab and click the **Hardware** tile to display the types of components.
  - Storage system inventory: Includes all hardware alerts.
  - Storage system detail: Click a storage system tile and click the **Hardware Alerts** tile to view hardware alerts for the selected storage system in the **Monitoring** tab.
  - Parity Group inventory: Click a storage system tile and then click **Parity Groups** to open the inventory. Click the **Hardware Alerts** tile to view alerts for disks where parity groups are located.



**Note:** Ref Code mapping to trap descriptions is available in a file included with the installation media.

2. Click a component type to display details in the table. Review the details in order to resolve the issue.

## Monitoring data protection

Data protection monitoring enables you to monitor the status of each data protection task.

You can view jobs alerts for your data protections tasks in a single page. Data protection alerts can be viewed by storage system and by server, and are available for the aggregated storage systems.

Alerts for the following operations are available:

- Failed Clone Now operations
- Failed Snapshot operations

A red circle with a number in a Data Protection alerts tile indicates the number of primary volumes and servers on which data protection tasks have failed. You can click the tile to investigate failed tasks.

## Procedure

1. View data protection alerts for the following resources:
  - All data protection alerts:
    - From the dashboard, click **Monitoring** or **Data Protection Alerts** to open the **Monitoring** tab.
    - Click **Storage Systems** on the dashboard and then click **Data Protection Alerts** to open the **Monitoring** tab.
  - A single storage system: Click **Storage Systems** and then click a storage system tile. Click the **Data Protection Alerts** tile to open the **Monitoring** tab.
  - Volumes attached to a single server: Click **Servers** from the dashboard and click a **Server** tile. Then click **Data Protection Alerts** to open the **Monitoring** tab.  
 The volumes inventory for a server includes failed tasks marked by an exclamation point. Click an exclamation point to view all volumes with failed tasks in the **Monitoring** tab.
2. Click the **Data Protection** tile in the **Monitoring** tab to open the carousel and then click **Volumes** to display details that can help you identify the issue. You can click the exclamation point for any failed task to view details for the volume.  
 GAD pairs with the status **PSUE** are displayed.

## Monitoring jobs

View the Jobs page to get an update on the status of a task or to view the errors associated with a job.





## Procedure

1. If there is a red circle with a number in the **Jobs Alert** tile, it reflects the number of failed jobs and jobs that succeeded with errors. Access the Jobs page in one of these ways:
  - From the dashboard, click **Jobs Alerts** to open the **Jobs** page, or click the **Jobs** tab.
  - On the dashboard, click **Storage Systems** to open the storage systems inventory. If the **Jobs Alert** tile has a red circle with a number, click it to view the Jobs page.
  - In the storage systems inventory, click a storage system tile. If the **Jobs Alert** tile has a red circle with a number, click it to view the inventory of jobs associated with the storage system.
2. The **Total Jobs** bar provides a graphical view of the relative number of jobs in each status. To filter jobs by status, click on the corresponding color in the Total Jobs bar.
3. View the status of jobs.

You can use the **Search** function to search by keyword. Common search terms include:

- Volume
- Pool
- Storage
- Create
- Provision
- Expand
- Delete

The **Status** column displays the job status.

Icon	Description
 success	The job completed successfully.
 success with errors	The job completed successfully, but there were errors.
 in progress	The job is still in progress.
 failed	The job failed.

4. Click a job to open the Job Details page where you can view any child jobs and reports associated with each job. Reports are the messages that the Storage Advisor service returns regarding the progress of each job. Child jobs serve to track jobs that launch multiple, smaller tasks (such as creating multiple volumes).

### Next steps

- If the job failed, review the job reports to determine the cause of the failure.
- If the job completed successfully with errors, click the job to view the error message.

## Setting up to receive SNMP alerts

If you are using external management software, you can add an SNMP (Simple Network Management Protocol) manager to enable alerts about devices in registered storage systems. This option is not required to monitor hardware in Hitachi Storage Advisor.

When an SNMP manager is added, it collects information from SNMP agents that are installed in components of registered storage systems. The storage systems send traps to Storage Advisor using SNMP v3.



**Note:** Storage Advisor manages such alerts automatically, for processors, memory, disks, power supplies, batteries, ports, caches, pools, and fans.



Storage Advisor uses SNMP v3 to send traps to external management software as soon as they are received. The structure of the traps is defined in a MIB file and Storage Advisor uses its own MIB file to add information to traps received so that the trap is easier to understand. It is important to import the Storage Advisor file to access the additional information. The Storage Advisor MIB file is included in the product installation media.

The SNMP manager enables you to do the following in the external software:

- Determine whether there are any problems with storage system components or whether the status is normal.
- Identify the specific component that in warning or critical status.

The following types of components can be monitored:

- Processor
- Memory
- Power supply
- Battery
- Fan
- Physical drive or disk
- Port
- Cache
- Pool

### Before you begin

SNMP management requires:

- External management software capable of receiving SNMP alerts.
- SNMP agents must be configured in the storage environment.
- The Storage Advisor MIB file has been imported to the SNMP manager.

### Procedure

1. Click **Settings** and select **SNMP Settings** to open the **SNMP** page. Click the plus sign (+) to open the **SNMP Manager Management** page.
2. Enter the following details:
  - **Name:** up to 32 characters.



**Note:** If you are editing an existing SNMP manager, Name cannot be edited.

- **Username** of the SNMP manager
- **IP Address:** of the SNMP manager.
- **Port:** Positive integers from 0 to 65535. are allowed.

- (Optional) **Privacy Protocol:** You can choose from the following:
  - **NO\_PRIV:** No privacy protocol.
  - **DES:** Data Encryption Standard.
  - **TRIPLE\_DES:** Triple Data Encryption Algorithm
  - **AES-128:** Advanced Encryption Standard.
- **Privacy Password:** If you choose a privacy protocol, you must enter a password.
- **Auth Protocol:** If you choose a privacy protocol, you must also select an authentication protocol. The choices are **MD5**, **SHA**, or **NO\_AUTH**.
- **Auth Password:** If you are using an authentication protocol, you must enter a password.



3. Click **Submit**.

## Result

A job is created to add or update an SNMP manager.

## Example

The following images show the difference between a trap with the MIB file imported and a trap without the MIB file in use.



---

## Chapter 10: Administer Storage Advisor

Access Storage Advisor administration tasks in Virtual Appliance Manager or through the Settings icon (⚙️) in the top navigation menu.

### Administering security

Storage Advisor comes with a default local user that has permissions for all operations in Storage Advisor.

On a regular basis, you can change the password of the local user by accessing Change Local Password in Settings in the top navigation menu.

If you want to provide more granular control to your users, you can use role-based access to control the operations that can be managed by different users. To do so, you must first add your LDAP server as the source of authentication. Storage Advisor supports adding one external LDAP server.

You can then assign Storage Advisor roles to user groups that exist in the Active Directory account domain. Members of the user groups will use the assigned user roles, and therefore, only the privileges attached to those user roles.

### Privileges and roles

Access to the storage system is restricted by roles. Roles determine what a user can and cannot do. The security administrator can grant access to users by assigning users roles with privileges that are attached to those specific roles.

Roles	Privileges
System administrator	<ul style="list-style-type: none"><li>▪ Addition, administration, and deletion of servers, storage system, and fabric switches, SNMP manager, and tier management.</li><li>▪ Addition, administration, and deletion of parity groups.</li><li>▪ Addition, administration, and deletion of virtual file server resource groups.</li></ul>

Roles	Privileges
	<ul style="list-style-type: none"> <li>▪ Read-only privileges to monitor everything in Storage Advisor.</li> <li>▪ Registration of Data Instance Director in Storage Advisor.</li> </ul>
Storage administrator	<ul style="list-style-type: none"> <li>▪ Addition, administration, and deletion of pools.</li> <li>▪ Addition, administration, and deletion of volumes, including creating, attaching to hosts, and data protection.</li> <li>▪ Addition, administration, and deletion of port configurations.</li> <li>▪ Read-only privileges to monitor everything in Storage Advisor.</li> </ul>
Security administrator	<ul style="list-style-type: none"> <li>▪ Addition, administration and deletion of remote account domains.</li> <li>▪ User role assignment to groups.</li> <li>▪ Read-only privileges to monitor everything in Storage Advisor.</li> </ul>

## Adding an account domain

Add an account domain so you can assign roles to user groups.



**Note:** Once a fully qualified domain for a current active directory server is added, you can change the credentials on an ongoing basis and save the changes. To update the fully qualified AD domain name, remove the existing Account Domain and add a new one.

### Procedure

1. Click **Settings** and select **Security** to open the **Security** page.
2. In the **Account Domain** field, enter the fully qualified domain name for the active AD server.
3. Enter the Active Directory server **Username** and **Password**. Storage Advisor uses these credentials to connect to the external domain and get the list of user groups in the Active Directory source. You can assign Storage Advisor roles to these user groups. Storage Advisor does not modify the user groups in the Active Directory source.
4. Click **Submit**.  
Changes take effect immediately.

### Next steps

When the job is complete, you can assign user roles.

## Assigning user roles

After adding an external LDAP source to Storage Advisor, you can assign Storage Advisor roles to user groups.

More than one role can be assigned to a user group. In this case the user will have permissions for multiple roles.

Once a role is assigned to a user group, you can change the role assignment and save it.

### Before you begin

Add an account domain.

### Procedure

1. Access the **Security** page by opening the settings menu and then selecting **Security Settings**.
2. In the **Group Name** field, type in a user group name from the account domain. Partial matches automatically populate the field.
3. In the **User Role** field, select an Storage Advisor user role:
  - **SecurityAdministrator**: Includes privileges needed for the following:
    - Addition, administration, and deletion of remote account domains.
    - User role assignment to groups.
    - Read-only privileges to monitor everything in Storage Advisor.
  - **SystemAdministrator**: Includes privileges needed for the following:
    - Addition, administration, and deletion of servers, storage, and fabric switches, onboarding of storage (block storage with or without NAS modules), SNMP manager, and tier management.
    - Addition, administration, and deletion of parity groups and port configurations.
    - Addition, administration, and deletion of virtual file server resource groups.
    - Read-only privileges to monitor everything in Storage Advisor.
  - **StorageAdministrator**: Includes privileges needed for storage provisioning and data protection:
    - Addition, administration, and deletion of pools.
    - Addition, administration, and deletion of volumes, including creating, attaching to servers, and data protection.
    - Read-only privileges to monitor everything in Storage Advisor.
4. Click the plus sign (+).
5. Click **Submit**.  
The changes take effect immediately.

**Example**

For example, there might be a user group named "IT" in the account domain, whose members need to perform security functions in Storage Advisor. Assigning the User Role "SecurityAdministrator" to the Group Name "IT" would give security administration privileges to all members of "IT".

## Backup and restore system settings

Use Virtual Appliance Manager to backup system settings before moving Storage Advisor to another instance.

The settings include configuration files, an email template file and an SQL file.

**Procedure**

1. Open a browser and enter `https://ip-address/vam/` to access the Virtual Appliance Manager and adjust the settings for your server environment.
  - User name: service
  - Password: Chang3Me!
2. Click **Backup** to download a tar.gz file containing system settings.
3. When you are ready to restore, log in to Virtual Appliance Manager
4. Click **Restore** and either drag and drop the backup file or click the plus sign (+).
5. Click **Submit**. The restore operation may take up to an hour.



**Note:** Do not cancel the restore operation. Cancellation may corrupt the Storage Advisor instance. The progress bar may indicate 100% completion even though the operation has not completed.

The Storage Advisor appliance restarts.

## System elements preserved during backup

The following system elements are preserved as part of the backup:

- Element inventories: Storage Systems, Servers, and Fabric Switch inventories are preserved.
- SNMP Managers: Locations for forwarding SNMP traps are preserved.
- Jobs: All jobs on the system are preserved.
- Alerts: Monitoring alerts are preserved.
- Tier Names: Tier names for HDT pools are preserved.
- Security information: Local usernames and passwords, as well as integrated Active Directories are preserved.
- Replication groups: All copy groups and replication groups and their associated snapshot schedules are preserved.
- Virtual Appliance Manager settings: Connected NTP servers, log level settings, SSL certificate and service settings are preserved. Host settings are not preserved.
- Migration tasks: All migration tasks and their associated migration pairs are preserved.

## Download the system log file

### Procedure

1. Open a browser and enter `https://ip-address/vam` in the address bar.  
User name: `service`  
Password: `Chang3Me!`
2. Click the **Download Logs** icon in the left menu.  
It may take a couple of minutes for the system to respond as it compiles the logs.
3. Open the zip file that contains the system logs.

---

# Index

## A

- accelerated data compression [38](#)
- account domain
  - adding [140](#)
- Active Directory [139](#)
- administration [139](#)
- administrator [61](#)
- alerts [132](#)
- audience [7](#)

## B

- backup
  - elements preserved [143](#)
- block storage
  - configuring [25](#)

## C

- capacity
  - monitoring [132](#)
- cloning [92](#), [93](#)
- copy group
  - renaming [99](#)

## D

- dashboard
  - analyzing data [18](#)
- data compression [38](#)
- data protection
  - cloning [93](#)
  - monitoring [134](#)
  - snapshots [94](#)
- data protection concepts [92](#)
- deduplication [72](#)
- Device Manager - Storage Navigator
  - accessing [58](#)
  - using [58](#)
- devices
  - monitoring [133](#)

## E

- EVS
  - details [85](#)
  - inventory [84](#)
- EVSs
  - creating [84](#)
- exports
  - creating [88](#)
  - details [88](#)
  - updating [88](#)
- external parity groups [37](#)

## F

- fabric switches
  - adding [27](#)
  - supported models [28](#)
  - system requirements [28](#)
- file pool
  - details [83](#)
- file pools
  - creating [81](#)
  - expanding [83](#)
  - inventory [80](#)
  - managing [80](#)
- file storage
  - configuring [80](#)
- file system
  - inventory [85](#)
- file systems
  - creating [86](#)
  - deleting [86](#)
  - expanding [87](#)
  - managing [85](#)
  - mounting/unmounting [86](#)
  - updating [87](#)
  - viewing details [86](#)

## G

- GAD [103](#)



getting started [12](#)  
global-active device [103](#)

## H

hardware [133](#)  
Hardware Alerts [133](#)  
HNAS 13.5 [61](#)  
hosts  
    updating [69](#)  
hsa 3.1 [92](#)

## I

inventory [20](#)

## J

job status [135](#)  
jobs  
    monitoring [135](#)

## L

log  
    download [143](#)  
LUN paths  
    editing [70](#)

## M

migrate volumes [121](#)  
monitoring  
    capacity [132](#)  
    data protecting [134](#)  
    hardware [133](#)  
    jobs [135](#)

## N

NAS Manager  
    accessing [61](#)  
    using for advanced file storage configuration [61](#)

## O

overview [12](#)

## P

parity groups  
    creating [29](#)  
    initializing [34](#)  
    inventory [34](#)

parity groups (*continued*)  
    reserved for NAS firmware [34](#)  
    status [34](#)  
parity groups, creating  
    advanced method [32](#)  
    basic method [30](#)  
password  
    local, changing [14](#)  
pool creation  
    basic method, calculation of pool sizes [43](#)  
pools  
    creating [38](#)  
    creating with advanced method [43](#)  
    expanding [45](#)  
    inventory [39](#)  
    updating [45](#)  
    viewing details [45](#)  
pools, creating [40](#)  
ports  
    enabling security [25](#)  
privileges [139](#)  
privileges and roles [139](#)  
product version [7](#)

## R

remote replication [107](#)  
replication [92](#)  
replication groups  
    editing [101](#)  
    inventory [99](#)  
    viewing [99](#)  
resources [20](#)  
roles  
    security administrator, storage administrator,  
    system administrator [139](#)  
Roles [59](#)

## S

security  
    administering [139](#)  
security administrator [139](#)  
servers  
    adding [63](#)  
    attach existing volumes [66](#)  
    create and attach volumes [66](#)  
    delete [66](#)  
    details [67](#)  
    edit [66](#)  
    inventory [66](#)  
Settings menu [14](#)

- shares
  - adding AD groups to [89](#)
  - creating [88](#)
  - details [89](#)
  - updating [90](#)
- shares and exports
  - inventory [87](#)
  - managing [87](#)
- snapshots [92, 94](#)
- SNMP alerts
  - enabling [136](#)
- SNMP manager
  - adding [136](#)
  - updating [136](#)
- spares
  - managing [34](#)
- storage administrator [139](#)
- storage system
  - adding [23](#)
  - configuration workflow [22](#)
  - editing [63](#)
  - onboarding
    - workflow [21](#)
  - updating [63](#)
- storage systems
  - deleting [54](#)
  - details [54](#)
  - editing [54](#)
  - inventory [53](#)
  - managing [53](#)
- system administrator [139](#)
- system log
  - download [143](#)

## T

- tiers
  - managing [63](#)

## U

- unified management
  - overview [13](#)
- user groups
  - roles [59](#)
- user roles
  - assigning [141](#)

## V

- virtual appliance manager
  - download system log [143](#)

- virtual file server
  - deleting [84](#)
  - details [85](#)
  - enabling/disabling [84](#)
  - inventory [84](#)
  - renaming [85](#)
- virtual file servers
  - creating [84](#)
- virtual storage machine
  - inventory page [103](#)
  - VSM [103](#)
- volume details [92](#)
- volume migration [121](#)
- volumes
  - attaching [51, 74](#)
  - cloning [93](#)
  - create and attach [49](#)
  - create and attach to servers [22](#)
  - details [102](#)
  - expanding [77](#)
  - inventory [77](#)
  - managing [72](#)
  - snapshots [94](#)
  - updating [77](#)
- volumes, creating [49, 72](#)
- vsm [113](#)

## W

- workflow
  - configuring a storage system [22](#)
  - onboarding a storage system [21](#)

## Hitachi Vantara



Corporate Headquarters

2535 Augustine Drive

Santa Clara, CA 95054 USA

[HitachiVantara.com](http://HitachiVantara.com) | [community.HitachiVantara.com](http://community.HitachiVantara.com)

Contact Information

USA: 1-800-446-0744

Global: 1-858-547-4526

[HitachiVantara.com/contact](http://HitachiVantara.com/contact)